



Agilent 1200 Series Thermostatted Column Compartment G1316A/G1316B/G1316C



Service Manual



Agilent Technologies

Notices

© Agilent Technologies, Inc. 1995, 1996-2008

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Agilent Technologies, Inc. as governed by United States and international copyright laws.

Manual Part Number

G1316-90111

Edition

09/2008

Printed in Germany

Agilent Technologies
Hewlett-Packard-Strasse 8
76337 Waldbronn

Research Use Only

Not for use in Diagnostic Procedures.

Manual Structure

The *Service Manual G1316-90111* (English) contains the complete information about the Agilent 1200 Series Thermostatted Column Compartment. It is available as Adobe Reader file (PDF) only.

Latest versions of the manuals can be obtained from the Agilent web.

Warranty

The material contained in this document is provided “as is,” and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Agilent disclaims all warranties, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Agilent shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein. Should Agilent and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.

Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as “Commercial computer software” as defined in DFAR 252.227-7014 (June 1995), or as a “commercial item” as defined in FAR 2.101(a) or as “Restricted computer software” as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause. Use, duplication or disclosure of Software is subject to Agilent Technologies’ standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will

receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

Safety Notices

CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a **WARNING** notice until the indicated conditions are fully understood and met.

In This Guide...

This manual covers the Agilent 1200 Series Thermostatted Column Compartments (TCC)

- *G1316A* Agilent 1200 Series TCC
- *G1316B* Agilent 1200 Series TCC SL
- *G1316C* Agilent 1200 Series TCC SL Plus

1 Introduction to the Column Compartment

This chapter gives an introduction to the TCC, instrument overview and internal connectors.

3 Installing the Column Compartment

This chapter describes the installation of the Thermostatted Column Compartment.

4 How to optimize the Column Compartment

This chapter provides information on how to optimize the Thermostatted Column Compartment.

5 Troubleshooting and Diagnostics

Overview about the troubleshooting and diagnostic features.

6 Error Information

This chapter describes the meaning of error messages, and provides information on probable causes and suggested actions how to recover from error conditions.

7 Test Functions

This chapter describes the TCC's built in test functions.

In This Guide...

8 Maintenance

This chapter describes the maintenance of the TCC.

9 Repair

This chapter gives instructions on how to repair the TCC.

10 Parts and Materials for Maintenance

This chapter provides information on parts for maintenance.

11 Parts for Repairs

This chapter provides information on parts for repair.

12 Identifying Cables

This chapter summarizes information on all cables.

13 Hardware Information

This chapter describes the detector in more detail on hardware and electronics.

14 Appendix

This chapter provides addition information on safety, legal and web.

Contents

1	Introduction to the Column Compartment	9
	Main Features	10
	System Overview	11
	Column-Identification System	13
	Column Switching Valve (Optional for G1316A/G1316B SL)	15
	Electrical Connections	18
	Instrument Layout	21
	Agilent Lab Advisor Software	22
2	Site Requirements and Specifications	23
	Site Requirements and Specifications	24
	Physical Specifications	27
	Performance Specifications	28
	Extended Specifications on G1316B SL/G1316C SL Plus	30
3	Installing the Column Compartment	33
	Unpacking the Column Compartment	34
	Optimizing the Stack Configuration	35
	Installing the Column Compartment	38
	Installing Valve Heads (G1316C SL Plus)	42
	Flow Connections of the Column Compartment	44
	Installation of Heater and Cooling Devices	47
	Placing Columns	49
4	How to optimize the Column Compartment	51
	Optimizing the Performance of your Column Compartment	52
	Using Additional Heater and Cooling Devices	53

5	Troubleshooting and Diagnostics	55
	Overview of the Column Department's Indicators and Test Functions	56
	Status Indicators	57
	Available Tests depending on User Interfaces	59
	Agilent Lab Advisor Software	60
6	Error Information	61
	What Are Error Messages	62
	General Error Messages	63
	TCC Error Messages	67
7	Test Functions	75
	Thermostat Function Test	76
	Pressure Test	79
	Column Thermostat Temperature Calibration	80
8	Maintenance	85
	Introduction to Maintenance and Repair	86
	Warnings and Cautions	87
	Overview of Maintenance	89
	Cleaning the Column Compartment	90
	Changing Column Identification Tags	91
	Replacing Head Parts of Column Switching Valve (G1316A/G1316B SL)	93
	Adding Heater and Cooling Devices (G1316B SL/G1316C SL Plus)	96
	Correcting Leaks	99
	Replacing the Column Compartment's Firmware	100
	Replacing Valve Heads (G1316C SL Plus)	101
	Preparing the G1316C SL Plus for Transportation	104

9 Repair 107

Cautions and Warnings 108
 Removing the Top Cover and Foam 110
 Removing a Valve 114
 Installing a Valve 119
 Exchanging the Main Board 124
 Changing the Type and Serial Number 129
 Exchanging the Fan 138
 Removing the Heat Exchanger Assemblies 140
 Installing the Heat Exchanger Assemblies 145
 Exchanging the Power Supply 152
 Replacing the Leak Sensor or Leak Base (G1316A/G1316B SL) 156
 Replacing Status Light Pipe 161
 Installing the Foam and the Top Cover 162
 Assembling the Main Cover 168
 Installing the Radio Frequency Shield (G1316C SL Plus) 170
 Installing the leak sensor (G1316C SL Plus) 172
 Replacing the Door Sensor (G1316C SL Plus) 174

10 Parts and Materials for Maintenance 177

Valve Options Overview 178
 Heater and Cooling Devices for G1316B SL/G1316C SL Plus 179
 Column Switching Valve 2 Position/6 Port (G1316A/G1316B SL) 181
 Column Switching Valve 8 Position/9 Port (G1316C SL Plus) 183
 Micro Column Switching Valve 2 Position/6 Port (G1316A/G1316B SL) 185
 Micro Column Switching Valve 2 Position/10 Port (G1316A/G1316B SL) 186
 Accessory Kits 188
 Plastic Parts 195
 Leak Parts 196

11	Parts for Repairs	199
	Overview of Main Assemblies	200
	Sheet Metal Kit	203
	Plastic Parts	205
	Foam Parts	207
	Power and Status Light Pipes	209
	Leak Parts	210
	Internal Valve Drive Parts (G1316C SL Plus)	212
12	Identifying Cables	213
	Cable Overview	214
	Analog Cables	216
	Remote Cables	219
	BCD Cables	224
	Auxiliary Cable	226
	CAN/LAN Cables	227
	External Contact Cable	228
	RS-232 Cables	229
13	Hardware Information	231
	The Electronics	232
	Firmware Description	233
	Agilent 1200 Series Interfaces	235
	Setting the 8-bit Configuration Switch	239
	The Main Power Supply Assembly	244
14	Appendix	247
	Safety Symbols	248
	The Waste Electrical and Electronic Equipment Directive	251
	Lithium Batteries Information	252
	Radio Interference	253
	Sound Emission	254
	Solvent Information	255
	Agilent Technologies on Internet	257



1 Introduction to the Column Compartment

Main Features	10
System Overview	11
Column-Identification System	13
Column Switching Valve (Optional for G1316A/G1316B SL)	15
Electrical Connections	18
Serial Number Information	20
Instrument Layout	21
Agilent Lab Advisor Software	22

This chapter gives an introduction to the TCC, instrument overview and internal connectors.



Main Features

The Agilent 1200 Series thermostatted column compartments are stackable temperature-controlled column compartments for LC. They are available as standalone modules or as a component of a Agilent 1200 Series system. They are used for heating and cooling to meet extreme requirements of retention time reproducibility.

The main features are:

- Peltier heating and cooling from 10 degrees below ambient up to 80 °C(G1316A) or 100 °C (G1316B SL/G1316C SL Plus) with high heating and cooling speeds for maximum application flexibility and stability,
- holds up to three 30-cm columns and optimized design gives minimum dead volumes and maximum efficiency,
- two independently programmable heat exchangers contribute volumes of only 3 and 6 µl,
- G1316B SL features additional heating and cooling devices for low flow rates, which reduce the risk of additional dispersion,
- G1316B SL and G1316C SL Plus can be supplemented by a kit to install a small heat-exchanger with 1.6 µl delay volume to reduce the delay volume. In addition a cooling device with 1.5 µl is available,
- electronic column-identification module as standard for GLP documentation of column type, and major column parameters,
- optional high-quality Rheodyne[®] column switching valves with ceramic stator-face assemblies for prolonged lifetime.

For specifications, see “[Performance Specifications](#)” on page 28.

System Overview

The Concept of Heating and Cooling

The design of this thermostatted column compartment uses column heating and cooling devices with Peltier elements. The solvent entering the column compartment is heated up or cooled down to a settable temperature with two low-volume heat exchangers (3 μl on left side, 6 μl on right side), made of a short piece of capillary 0.17 mm i.d. leading through a heat exchanger. The heat exchanger is designed such that it can function simultaneously as an air heater. The shape of the heat exchanger surface allows the area around the column to be kept at a similar temperature level as the liquid running through the column. This is done by thermal convection and radiation between the heat exchanger fins. This design ensures that the column and the solvent flowing through it are almost at the same temperature.

Actual temperature control is accomplished at the heat exchanger. The solvent cools down or heats up on its transfer from the heating block to the column inlet. This depends on several factors: flow rate, setpoint temperature, ambient temperature and column dimensions.

In a flow-through temperature regulation system, there are necessarily slightly different temperatures at different positions. If, for example, the temperature set by the user is 40 $^{\circ}\text{C}$, then the heat exchanger is regulated to a temperature 40.8 $^{\circ}\text{C}$ which is different by a certain offset (here. 0.8 $^{\circ}\text{C}$). The solvent temperature at the column entry would be about 39 $^{\circ}\text{C}$.

The actual temperature displayed on the user interface is always the derived temperature taken at the heat exchanger, corrected by the offset explained above.

Any type of heated column compartment brings one important consequence for column temperature equilibration. Before an equilibrium is reached, the whole mass of column, column packing, and solvent volume inside the column has to be brought to the selected temperature. This depends on several factors: flow rate, setpoint temperature, ambient temperature and column dimensions. The higher the flow rate, the faster the column equilibrates (due to thermostatted mobile phase).

1 Introduction to the Column Compartment System Overview

“Column Thermostat Temperature Calibration” on page 80 shows a setpoint temperature of 40 °C. Some time after entering the setpoint the heat exchanger has reached its temperature and the control activity starts. The **TEMPERATURE NOT READY** signal will be cancelled 20 seconds after the sensed temperature was within a range of ± 0.5 °C of the setpoint (other values can be set via the user interface). However this does not necessarily mean that the column has already reached the correct temperature. The equilibration of the column may take longer. Stability of the pressure signal is a good indication for equilibrium.




Figure 1 Equilibration of Heat Exchanger and Column Temperature

The temperature calibration and verification is described in “Column Thermostat Temperature Calibration” on page 80.

Column-Identification System

The Agilent 1200 Series thermostatted column compartment is equipped with a column-identification system. It allows to read and write column-specific information to and from the column-identification tag.




Figure 2 Column-Identification System

[Table 1](#) on page 14 shows the information that can be stored. The information fields can be edited via the user interface.

1 Introduction to the Column Compartment

Column-Identification System

Table 1 Column-Identification Module Information

Item	Example	Comment
Product number	799160D-552	
Serial number	950522	Date of manufacturing
Batch number	1675	
Geometry [mm]	100 × 2.1	
Stationary phase	ODS Hypersil	
Particle size	10 µm	
Number of injections	1267	See Note below.
Maximum pressure allowed [bar]	400	
Maximum temperature recommended [°C]	70	
Maximum pH recommended	12	
Column void volume [ml]		

The number of injections will be updated each run to create a column lifecycle (history). The user interface allows to edit all information.

NOTE

If a column switching valve (see “[Column Switching Valve \(Optional for G1316A/G1316B SL\)](#)” on page 15) is installed in the module, the update of the number of injections depends on the position of the column switching valve. For example, if the left column is selected, the right column is not updated, and vice versa. If no column switching valve is installed both sides are updated at the same time.

Column Switching Valve (Optional for G1316A/G1316B SL)




Figure 3 Location of Column Switching Valve

1 Introduction to the Column Compartment

Column Switching Valve (Optional for G1316A/G1316B SL)

Two Column Selection

The valve can select either column 1 or column 2. The offline column is sealed by connecting head to tail. Switching should be done when the flow is off and the pressure is zero.

NOTE

Before switching the valve, switch off the pump or set the flow to zero. Keeping the flow on while the valve is switched can cause exceeding the maximum pressure. This will stop method or sequence execution.




Figure 4 Column 1 Active




Figure 5 Column 2 Active

Precolumn Back-flushing

The sample is injected into series-connected precolumn and analytical column. After the valve has switched, the analytical column flow continues in normal direction. Only the precolumn is back-flushed, eluting highly retained peaks directly to the detector.




Figure 6 Precolumn Back-flushing

Electrical Connections

- The CAN bus is a serial bus with high speed data transfer. The two connectors for the CAN bus are used for internal Agilent 1200 Series module data transfer and synchronization.
- One analog output provides signals for integrators or data handling systems.
- The REMOTE connector may be used in combination with other analytical instruments from Agilent Technologies if you want to use features such as start, stop, common shut down, prepare, and so on.
- With the appropriate software, the RS-232C connector may be used to control the module from a computer through a RS-232C connection. This connector is activated and can be configured with the configuration switch. See your software documentation for further information.
- The power input socket accepts a line voltage of 100 – 240 volts AC \pm 10% with a line frequency of 50 or 60 Hz. Maximum power consumption is 220 VA. There is no voltage selector on your module because the power supply has wide-ranging capability. There are no externally accessible fuses, because automatic electronic fuses are implemented in the power supply. The security lever at the power input socket prevents the module cover from being taken off when line power is still connected.

NOTE

Never use cables other than the ones supplied by Agilent Technologies to ensure proper functionality and compliance with safety or EMC regulations.




Figure 7 Rear View of Oven - Electrical Connections and Label

Serial Number Information

The serial number information on the instrument labels provide the following information:

CCYWWSSSSS	Format
CC	country of manufacturing <ul style="list-style-type: none">• DE = Germany• JP = Japan• CN = China
YWW	year and week of last major manufacturing change, e.g. 820 could be week 20 of 1998 or 2008
SSSSS	real serial number

Instrument Layout

The industrial design of the module incorporates several innovative features. It uses Agilent's E-PAC concept for the packaging of electronics and mechanical assemblies. This concept is based upon the use of expanded polypropylene (EPP) layers foam plastic spacers in which the mechanical and electronic boards components of the module are placed. This pack is then housed in a metal inner cabinet which is enclosed by a plastic external cabinet. The advantages of this packaging technology are:

- virtual elimination of fixing screws, bolts or ties, reducing the number of components and increasing the speed of assembly/disassembly,
- the plastic layers have air channels molded into them so that cooling air can be guided exactly to the required locations,
- the plastic layers help cushion the electronic and mechanical parts from physical shock, and
- the metal inner cabinet shields the internal electronics from electromagnetic interference and also helps to reduce or eliminate radio frequency emissions from the instrument itself.

Agilent Lab Advisor Software

The Agilent Lab Advisor Software is a standalone product that can be used with or without data system. Agilent Lab Advisor helps to manage the lab for high quality chromatographic results and can monitor in real time a single Agilent LC or all the Agilent GCs and LCs configured on the lab intranet.

Agilent Lab Advisor provides diagnostic capabilities for all Agilent 1200 Series HPLC modules. This includes tests and calibrations procedures as well as the different injector steps to perform all the maintenance routines.

Agilent Lab Advisor also allows users to monitor the status of their LC instruments. The Early Maintenance Feedback (EMF) feature helps to carry out preventive maintenance. In addition, users can generate a status report for each individual LC instrument. The tests and diagnostic features as provided by the Agilent Lab Advisor Software may differ from the descriptions in this manual. For details refer to the Agilent Lab Advisor help files.

This manual provides lists with the names of Error Messages, Not Ready messages, and other common issues.



2 Site Requirements and Specifications

Site Requirements and Specifications	24
Power Consideration	24
Power Cords	25
Bench Space	26
Environment	26
Physical Specifications	27
Performance Specifications	28
Extended Specifications on G1316B SL/G1316C SL Plus	30



Site Requirements and Specifications

A suitable environment is important to ensure optimal performance of the instrument.

Power Consideration

The module power supply has wideranging capability (see [Table 2](#) on page 27). It accepts any line voltage in the range described in the above mentioned table. Consequently there is no voltage selector in the rear of the module. There are also no externally accessible fuses, because automatic electronic fuses are implemented in the power supply.

WARNING

Incorrect line voltage at the instrument

Shock hazard or damage of your instrumentation can result, if the devices are connected to a line voltage higher than specified.

→ Connect your instrument to the specified line voltage.

WARNING

Module is partially energized when switched off, as long as the power cord is plugged in.

Repair work at the module can lead to personal injuries, e.g. shock hazard, when the cover is opened and the module is connected to power.

→ Remove the power cable from the instrument before opening the cover.

→ Do not connect the power cable to the Instrument while the covers are removed.

CAUTION

Unaccessible power plug.

In case of emergency it must be possible to disconnect the instrument from the power line at any time.

- Make sure the power connector of the instrument can be easily reached and unplugged.
 - Provide sufficient space behind the power socket of the instrument to unplug the cable.
-

Power Cords

Different power cords are offered as options with the module. The female end of all power cords is identical. It plugs into the power-input socket at the rear of the module. The male end of each power cord is different and designed to match the wall socket of a particular country or region.

WARNING

The absence of ground connection and the use of an unspecified power cord can lead to electric shock or short circuit.

Electric Shock

- Never operate your instrumentation from a power outlet that has no ground connection.
 - Never use a power cord other than the Agilent Technologies power cord designed for your region.
-

WARNING

Use of unsupplied cables

Using cables not supplied by Agilent Technologies can lead to damage of the electronic components or personal injury.

- Never use cables other than the ones supplied by Agilent Technologies to ensure proper functionality and compliance with safety or EMC regulations.
-

Bench Space

The column compartment dimensions and weight (see “[Physical Specifications](#)” on page 27) allow to place this module on almost any desk or laboratory bench. It needs an additional 2.5 cm (1.0 inches) of space on either side and approximately 8 cm (3.1 inches) in the rear for the circulation of air and electric connections.

If the bench should carry a complete Agilent Series system, make sure that the bench is designed to carry the weight of all the modules.

The module should be operated in a horizontal position.

Environment

Your column compartment will work within specifications at ambient temperatures and relative humidity as described in “[Physical Specifications](#)” on page 27.

Physical Specifications

Table 2 Physical Specifications

Type	Specification	Comments
Weight	10.2 kg (22.5 lbs)	
Dimensions (width × depth × height)	410 × 435 × 140 mm (16.1 × 17 × 5.5 inches)	
Line voltage	100 – 240 VAC, ± 10%	Wide-ranging capability
Line frequency	50 or 60 Hz, ± 5%	
Power consumption	320 VA / 150 W / 512 BTU	Maximum
Ambient operating temperature	0 – 55 °C (32 – 131 °F)	
Ambient non-operating temperature	-40–70 °C (-4–158 °F)	
Humidity	< 95%, at 25–40 °C (77–104 °F)	Non-condensing
Operating Altitude	Up to 2000 m (6500 ft)	
Non-operating altitude	Up to 4600 m (14950 ft)	For storing the module
Safety standards: IEC, CSA, UL	Installation Category II, Pollution Degree 2	For indoor use only. Research Use Only. Not for use in Diagnostic Procedures.

Performance Specifications

Table 3 Performance Specifications Thermostatted Column Compartment

Type	Specification	Comments
Temperature range	10 degrees below ambient to 80 °C	G1316A
	10 degrees below ambient to 100 °C	G1316B SL/G1316C SL Plus
	up to 80 °C: flow rates up to 5 ml/min up to 100 °C: flow rates up to 2.5 ml/min	G1316A/G1316B SL/G1316C SL Plus G1316B SL/G1316C SL Plus
Temperature stability	± 0.15 °C	G1316A
	± 0.05 °C	G1316B SL/G1316C SL Plus
Temperature accuracy	± 0.8 °C	With calibration
	± 0.5 °C	
Column capacity	Three 30 cm	
Warm-up/ cool-down time	5 minutes from ambient to 40 °C	
	10 minutes from 40 – 20 °C	
Dead volume	3 µl left heat exchanger	i.d. 0.17 mm, see “Extended Specifications on G1316B SL/G1316C SL Plus” on page 30
	6 µl right heat exchanger	
Communication s	Controller-area network (CAN), GPIB, RS-232C, APG Remote: ready, start, stop and shut-down signals, LAN via other 1200 series module	no GPIB on G1316B SL/G1316C SL Plus
Safety and maintenance	Extensive diagnostics, error detection and display (through control module and Agilent ChemStation), leak detection, safe leak handling, leak output signal for shutdown of pumping system. Low voltages in major maintenance areas.	

Table 3 Performance Specifications Thermostatted Column Compartment

Type	Specification	Comments
GLP features	Column-identification module for GLP documentation of column type, see “Column-Identification System” on page 13	
Housing	All materials recyclable.	

NOTE

All specifications are valid for distilled water at ambient temperature (25 °C), set point at 40 °C and a flow range from 0.2–5 ml/min.

Extended Specifications on G1316B SL/G1316C SL Plus

The 1200 series G1316B SL/G1316C SL Plus thermostatted column compartment is usable from 10 °C below ambient up to 80 °C for flow ranges up to 5 ml/min and up to 100 °C for flow ranges up to 2.5 ml/min. Additional heating and cooling devices are available for the G1316B SL/G1316C SL Plus to reduce the risk of additional dispersion at low flow rates see [Figure 8](#) on page 30. These devices can be installed in any position in the column compartment, see “[Installation of Heater and Cooling Devices \(G1316B SL\)](#)” on page 47.




Figure 8 New additional heater and cooling devices


The standard column compartment is equipped with a 3 μ l and 6 μ l heater or cooler. Both can be set at the same or different temperature. To reduce the delay volume, a kit (“[G1316B SL/G1316C SL Plus Capillary System Kit](#)” on page 190) has been set up for installing a small heaters with 1.6 μ l internal delay volume and also a new cooling device with 1.5 μ l internal volume is available.

NOTE

If the additional heater and cooling devices are used as shown in [Figure 8](#) on page 30, the column identification system cannot be used. If the column identification system is required, fix the heater and cooling devices in the upper or lower locations or fix them right/left of the current location.

2 Site Requirements and Specifications

Extended Specifications on G1316B SL/G1316C SL Plus



3 Installing the Column Compartment

Unpacking the Column Compartment	34
Delivery Checklist	34
Optimizing the Stack Configuration	35
Installing the Column Compartment	38
Installing Valve Heads (G1316C SL Plus)	42
Flow Connections of the Column Compartment	44
Installation of Heater and Cooling Devices	47
Placing Columns	49
Column-Identification Tag	49
Column Clip	50

This chapter describes the installation of the Thermostatted Column Compartment.



Unpacking the Column Compartment

If the delivery packaging shows signs of external damage, please call your Agilent Technologies sales and service office immediately. Inform your service representative that the module may have been damaged during shipment.

CAUTION

"Defective on arrival" problems

If there are signs of damage, please do not attempt to install the module. Inspection by Agilent is required to evaluate if the instrument is in good condition or damaged.

- Notify your Agilent sales and service office about the damage.
- An Agilent service representative will inspect the instrument at your site and initiate appropriate actions.

Delivery Checklist

Ensure all parts and materials have been delivered with the module. The delivery checklist is shown below. Please report missing or damaged parts to your local Agilent Technologies sales and service office.

Table 4 Column Compartment Delivery Checklist

Description	Quantity
Thermostatted column compartment	1
Power cable	1
CAN cable	1
Column switching valve	optional
User Manual	1
Accessory kit (see "Accessory Kits" on page 188)	1

Optimizing the Stack Configuration

If your column compartment is part of a Agilent 1200 Series system, you can ensure optimum performance by installing the following configuration. This configuration optimizes the system flow path and ensures minimum delay volume.

For installations of the G1316C SL Plus as part of the Method Development Solution, please refer to the Method Development Solution User and Installation Guide **part number: G4230-90000**.

3 Installing the Column Compartment Optimizing the Stack Configuration




Figure 9 Recommended Stack Configuration (Front View)




Figure 10 Recommended Stack Configuration (Rear View)

Installing the Column Compartment

Parts required	#	Description
	1	Column compartment
	1	Power cord
		For other cables see text below

Preparations	Locate bench space. Provide power connections. Unpack the Column compartment.
--------------	---

WARNING

Module is partially energized when switched off, as long as the power cord is plugged in.

Risk of stroke and other personal injury. Repair work at the module can lead to personal injuries, e. g. shock hazard, when the module cover is opened and the instrument is connected to power.

- Never perform any adjustment, maintenance or repair of the module with the top cover removed and with the power cord plugged in.
- The security lever at the power input socket prevents that the module cover is taken off when line power is still connected. Never plug the power line back in when cover is removed.

CAUTION

Valve properties are read from the valve head RFID tag during initialization of the module. Valve properties will not be updated, if the valve head is replaced while the module is on.

Selection of valve port positions can fail, if the instrument does not know the properties of the installed valve.

- Always switch off the instrument when replacing the valve head.


CAUTION

The valve actuator contains sensitive optical parts, which need to be protected from dust and other pollutions. Pollution of these parts can impair the accurate selection of valve ports and therefore bias measurement results.

→ Always install a valve head for operation and storage. For protecting the actuator, a dummy valve head (part of transportation lock kit **part number: G1316-67001**) can be used instead of a functional valve. Do not touch parts inside the actuator.

If the Thermostatted Column Compartment SL Plus (G1316C SL Plus only) includes the valve drive option, it is shipped with a transportation lock, which needs to be removed during installation.


1 Remove the 5 screws, which hold the lock in position (G1316C SL Plus only).



2 Remove the dummy valve head by unscrewing the cap nut and removing it from the valve drive (G1316C SL Plus only).

3 Installing the Column Compartment

Installing the Column Compartment



- 3 Place the column compartment in the stack or on the bench in a horizontal position.
- 4 Ensure the power switch at the front of the column compartment is OFF.

Status indicator
green/yellow/red

Line power switch
with green light




Figure 11 Front View of the Thermostatted Column Compartment

- 5 Connect the power cable to the power connector at the rear of the column compartment.

- 6 Connect the CAN cable to other Agilent 1200 Series modules.
- 7 If Agilent ChemStation is the controller, connect either
 - the LAN connection to the LAN interface board in the module or
 - the GPIB cable to the module.

NOTE

If a Agilent DAD/MWD/FLD is in the system, the LAN/GPIB should be connected to the DAD/MWD/FLD (due to higher data load).

- 8 Connect the APG Remote cable (optional) for non-Agilent 1200 Series instruments.
- 9 Turn ON power by pushing the button at the lower left side of the column compartment. The status LED should be green.




Figure 12 Rear View of the Thermostatted Column Compartment

NOTE

The column compartment is turned on when the line power switch is pressed and the green indicator lamp is illuminated. The column compartment is turned off when the line power switch is protruding and the green light is OFF.

Installing Valve Heads (G1316C SL Plus)

Several optional valve heads are available for the G1316C SL Plus, which can be installed and exchanged easily.

Parts required	#	Part number	Description
	1	5067-4107	8pos/9prt valve head high pressure and/or
	1	5067-4108	8pos/9prt valve head low pressure

CAUTION

Valve Damage

Using a low pressure valve on the high pressure side can damage the valve.

- When using multiple column compartments as part of a method development solution, make sure that the high pressure valve head is connected to the autosampler and the low pressure valve head is connected to the detector.
- For details, please refer to the Method Development Solution User and Installation Guide (**part number: G4230-90000**).


CAUTION

Column Damage or Bias Measurement Results


Switching the valve to a wrong position can damage the column or bias measurement results.

- Fitting the lobe to the groove is essential for making sure the valve is switched to the correct position.


1 Put the valve head onto the valve drive such that the lobe fits to the groove.




2 Screw the valve head onto the valve drive using the union nut.



3 Install all required capillary connections to the valve head.



4 Push the valve head until it snaps in and stays in the rear position.



3 Installing the Column Compartment

Flow Connections of the Column Compartment

Flow Connections of the Column Compartment

Parts required	Description
	Other modules
	Parts from accessory kit, see “Accessory Kits” on page 188
	Two wrenches 1/4 – 5/16 inch for capillary connections


Preparations Install the column compartment




WARNING

Toxic and hazardous solvents

The handling of solvents and reagents can hold health risks.

- When working with solvents observe appropriate safety procedures (for example, goggles, safety gloves and protective clothing) as described in the material handling and safety data sheet supplied by the solvent vendor, especially when toxic or hazardous solvents are used.




<p>NOTE</p> <p>For more information on column identification, see “Column-Identification System” on page 13 .</p>	<p>NOTE</p> <p>The internal volumes of the heat exchanger assemblies comprise a volume of 3 µl (left) and 6 µl (right). The internal capillary diameter is 0.17 mm.</p>
<p>3 Place the column on the left heat exchanger assembly and connect the capillaries to the column.</p> 	<p>4 Or place the column on the right heat exchanger assembly and connect the capillaries to the column.</p> 
<p>NOTE</p> <p>See “Column Switching Valve (Optional for G1316A/G1316B SL)” on page 15. on how to connect the column selection valve.</p>	<p>5 Fix the column with the column clip from the accessory kit.</p> 


3 Installing the Column Compartment

Flow Connections of the Column Compartment


- 6** If the column compartment is not part of a Agilent 1200 Series system, or if an Agilent 1200 Series Autosampler is located on top, connect the corrugated tubing to the waste outlet.



- 7** Route tubings from modules above through the openings in the funnel holder (top) and the plastic bottom part. Remove small plastic plugs first.



- 8** Put the front cover back in place.



The installation of the column compartment has now been completed.

NOTE

Always operated the TCC with the front cover in place for proper thermostating conditions and to protect the column area against strong drafts from the outside.

Installation of Heater and Cooling Devices

Installation of Heater and Cooling Devices (G1316B SL)

With the introduction of the 1200 series TCC SL (G1316B SL), the heater elements were redesigned in order to allow the adding of small heater and cooling devices.

NOTE

Depending on the application, these heater and cooling devices can be fixed at various places. Information about the usage of these heater and cooling devices can be found in Technical Notes or in the Agilent 1200 Series Rapid Resolution LC System manual (**part number: G1312-90300**).




Figure 13 Installation points for heat exchanger / cooling devices

NOTE

If the additional heat exchanger and cooling devices are used as shown in this figure, the column identification system cannot be used. If the column identification system is required, fix the heater and cooling devices in the upper or lower locations or right/left of the current location.

Installation of Heater and Cooling Devices (G1316C SL Plus)

For the G1316C SL Plus, additional heat exchanger and cooling devices can be installed on the carrier **part number: G1316-89200** using 3 screws (**part number: 0515-1052**, included to part number for carrier) as shown in figure below.




Figure 14 Installing the low dispersion heat exchangers

Placing Columns

Column-Identification Tag

When correctly placed on the heat exchanger, the distance between the column-identification tag and antenna is 1–2 mm. This is the optimum distance for proper function. The identification tag can be easily removed from the column.

NOTE

For columns with small diameter, a cable tie wrap should be used to fix the column identification tag to the column. Assure that the tie wrap does not block the front cover.

NOTE

The tag needs to be placed differently, depending on whether the column is installed at the left or right heat exchanger, see [Figure 15](#) on page 49 and [Figure 16](#) on page 50. The Agilent logo should always be at front.




Figure 15 Column-Identification Tag for Left Heat Exchanger

3 Installing the Column Compartment

Placing Columns




Figure 16 Column-Identification Tag for Right Heat Exchanger

Column Clip

For better positioning of the column on the heat exchanger a column clip is available (see “[Accessory Kits](#)” on page 188).




Figure 17 Column Clip (part number 5063-6526, pack of 6)



4 How to optimize the Column Compartment

Optimizing the Performance of your Column Compartment 52

Using Additional Heater and Cooling Devices 53

This chapter provides information on how to optimize the Thermostatted Column Compartment.



Optimizing the Performance of your Column Compartment

For best performance results of the column compartment:

- Use short connection capillaries and place them close to the heat exchanger. This will reduce heat dissipation and external band-broadening.
- Use the left heat exchanger for small volume columns, for example, 2–3 mm i.d. columns at flow rates of less than 200 $\mu\text{l}/\text{min}$.
- For even lower band-broadening, the heat exchanger can be by-passed and the column is placed well between the heat exchanger fins.
- Keep the left and right heat exchanger temperature the same unless you do specific applications.
- Assure that the front cover is always closed.

Using Additional Heater and Cooling Devices

The optimization, installation, interconnection, and specific settings when using additional heating and cooling devices are described in the Agilent 1200 Series Rapid Resolution LC System manual (G1312-90300).

4 How to optimize the Column Compartment

Using Additional Heater and Cooling Devices



5 Troubleshooting and Diagnostics

Overview of the Column Department's Indicators and Test Functions 56

Status Indicators 57

Power Supply Indicator 57

Module Status Indicator 57

Available Tests depending on User Interfaces 59

Agilent Lab Advisor Software 60

Overview about the troubleshooting and diagnostic features.



Overview of the Column Department's Indicators and Test Functions

Status Indicators

The instrument is provided with two status indicators which indicate the operational state (prerun, run, and error states) of the instrument. The status indicators provide a quick visual check of the operation of the instrument.

Error Messages

In the event of an electronic, mechanical or hydraulic failure, the instrument generates an error message in the user interface. The following pages describe the meaning of the error messages. For each message, a short description of the failure, a list of probable causes, and a list of suggested actions to fix the problem are provided.

Thermostat Diagnostic Test

The thermostat diagnostic test evaluates the heating and cooling efficiency of the two peltier elements.

Temperature Calibration and Verification

The temperature calibration and verification procedure enables the instrument temperature to be measured against an external, calibrated measuring device. Normally, temperature calibration is not required throughout the lifetime of the instrument. However, in order to comply with local regulatory requirements, calibration and verification may be required.

The following sections describe these functions in detail.

Status Indicators

Two status indicators are located on the front of the module. The lower left indicates the power supply status, the upper right indicates the instrument status.




Figure 18 Location of Status indicators

Power Supply Indicator

The power supply indicator is integrated into the main power switch. When the indicator is illuminated (*green*) the power is ON.

Module Status Indicator

The module status indicator indicates one of four possible instrument conditions:

- When the status indicator is OFF (and power switch indicator is on), the instrument is in a **prerun** condition, and is ready to begin an analysis.

5 Troubleshooting and Diagnostics

Status Indicators

- A *green* status indicator, indicates the module is performing an analysis (**run mode**).
- A *yellow* indicator indicates a **not-ready** condition. The module is in a not-ready state when it is waiting for a specific condition or action to be completed (for example, immediately after changing a setpoint), or while a self-test procedure is running.
- An **error** condition is indicated by a *red* status indicator. An error condition indicates the module has detected an internal problem which affects correct operation of the instrument. Usually, an error condition requires attention (for example, leak, defective internal components). The error state is propagated through the system to all connected modules, so the error might come from a different module. Check the error log of your user interface for the originating module. For safety reasons, an error condition always interrupts the analysis.

Available Tests depending on User Interfaces

NOTE

Depending on the used interface, the available tests and the screens/reports may vary. Preferred tool should be the Agilent Lab Advisor Software, see [“Agilent Lab Advisor Software”](#) on page 22.

Screenshots used in this document are based on the Agilent ChemStation. In future, the user interface may not show the Diagnostics/Tests anymore. In this case use the Agilent Lab Monitor Diagnostic (LMD) Software.

The Agilent ChemStation may not include any maintenance/test functions.

Table 5 Test Functions available vs. User Interface - TCC

Test	Agilent ChemStation	Instant Pilot G4208A	LMD Software
Thermostat Function Test	Yes	No	Yes
Temperature Calibration	Yes	Yes ¹	Yes

¹ section Maintenance

Agilent Lab Advisor Software

The Agilent Lab Advisor Software is a standalone product that can be used with or without data system. Agilent Lab Advisor helps to manage the lab for high quality chromatographic results and can monitor in real time a single Agilent LC or all the Agilent GCs and LCs configured on the lab intranet.

Agilent Lab Advisor provides diagnostic capabilities for all Agilent 1200 Series HPLC modules. This includes tests and calibrations procedures as well as the different injector steps to perform all the maintenance routines.

Agilent Lab Advisor also allows users to monitor the status of their LC instruments. The Early Maintenance Feedback (EMF) feature helps to carry out preventive maintenance. In addition, users can generate a status report for each individual LC instrument. The tests and diagnostic features as provided by the Agilent Lab Advisor Software may differ from the descriptions in this manual. For details refer to the Agilent Lab Advisor help files.

This manual provides lists with the names of Error Messages, Not Ready messages, and other common issues.



6 Error Information

What Are Error Messages 62

General Error Messages 63

TCC Error Messages 67

This chapter describes the meaning of error messages, and provides information on probable causes and suggested actions how to recover from error conditions.



What Are Error Messages

Error messages are displayed in the user interface when an electronic, mechanical, or hydraulic (flow path) failure occurs which requires attention before the analysis can be continued (for example, repair, frit exchange, exchange of consumable is necessary). In the event of such a failure, the red status indicator at the front of the column compartment is switched on, and an entry is written into the instrument logbook.

This section describes the meaning of error messages, and provides information on probable causes and suggested actions how to recover from error conditions.

General Error Messages

General error messages are generic to all Agilent 1200 Series HPLC modules.

Timeout

The timeout threshold was exceeded.

Probable cause

- 1** The analysis was completed successfully, and the timeout function switched off the module as requested.
- 2** A not-ready condition was present during a sequence or multiple-injection run for a period longer than the timeout threshold.

Suggested actions

- Check the logbook for the occurrence and source of a not-ready condition. Restart the analysis where required.
- Check the logbook for the occurrence and source of a not-ready condition. Restart the analysis where required.

Shut – Down

An external instrument has generated a shut-down signal on the remote line.

The module continually monitors the remote input connectors for status signals. A LOW signal input on pin 4 of the remote connector generates the error message.

Probable cause	Suggested actions
1 Leak detected in another module with a CAN connection to the system.	Fix the leak in the external instrument before restarting the module.
2 Leak detected in an external instrument with a remote connection to the system.	Fix the leak in the external instrument before restarting the module.
3 Shut-down in an external instrument with a remote connection to the system.	Check external instruments for a shut-down condition.
4 The degasser failed to generate sufficient vacuum for solvent degassing.	Check the vacuum degasser for an error condition. Refer to the <i>Service Manual</i> for the Agilent 1200 Series vacuum degasser.

Remote Timeout

A not-ready condition is still present on the remote input.

When an analysis is started, the system expects all not-ready conditions (e.g. a not-ready condition during detector balance) to switch to run conditions within one minute of starting the analysis. If a not-ready condition is still present on the remote line after one minute the error message is generated.

Probable cause	Suggested actions
1 Not-ready condition in one of the instruments connected to the remote line.	Ensure the instrument showing the not-ready condition is installed correctly, and is set up correctly for analysis.
2 Defective remote cable.	Exchange the remote cable.
3 Defective components in the instrument showing the not-ready condition.	Check the instrument for defects (refer to the instrument's reference documentation).

Synchronization Lost

During an analysis, the internal synchronization or communication between one or more of the modules in the system has failed.

The system processors continually monitor the system configuration. If one or more of the modules is no longer recognized as being connected to the system, the error message is generated.

Probable cause

- 1** CAN cable disconnected.
- 2** Defective CAN cable.
- 3** Defective main board in a different module.

Suggested actions

- Ensure all the CAN cables are connected correctly.
 - Ensure all CAN cables are installed correctly.
- Exchange the CAN cable.
- Switch off the system. Restart the system, and determine which module or modules are not recognized by the system.

Leak

A leak was detected in the column compartment module.

The signals from the two temperature sensors (leak sensor and board-mounted temperature-compensation sensor) are used by the leak algorithm to determine whether a leak is present. When a leak occurs, the leak sensor is cooled by the solvent. This changes the resistance of the leak sensor which is sensed by the leak-sensor circuit on the TCC board.

Probable cause

- 1** Condensation.
- 2** Loose column fittings.
- 3** Broken capillary.
- 4** Leaking column-switching valve seal.

Suggested actions

- Use a higher temperature setpoint.
- Ensure all fittings are tight.
- Exchange defective capillaries.
- Exchange the valve seal.

Leak Sensor Open

The leak sensor in the module has failed (open circuit).

The current through the leak sensor is dependent on temperature. A leak is detected when solvent cools the leak sensor, causing the leak-sensor current to change within defined limits. If the current falls outside the lower limit, the error message is generated.

Probable cause

- 1** Leak sensor not connected to the main board.
- 2** Defective leak sensor.
- 3** Leak sensor incorrectly routed, being pinched by a metal component.

Suggested actions

- Ensure the leak sensor is connected correctly.
- Exchange the leak sensor.
- Exchange the leak sensor.

Leak Sensor Short

The leak sensor in the module has failed (short circuit).

The current through the leak sensor is dependent on temperature. A leak is detected when solvent cools the leak sensor, causing the leak-sensor current to change within defined limits. If the current increases above the upper limit, the error message is generated.

Probable cause

- 1** Defective leak sensor.
- 2** Leak sensor incorrectly routed, being pinched by a metal component.

Suggested actions

- Exchange the leak sensor.
- Check routing of leak sensor “[Replacing the Leak Sensor or Leak Base \(G1316A/G1316B SL\)](#)” on page 156.

TCC Error Messages

The following errors are TCC specific error messages.

Compensation Sensor Open

The ambient-compensation sensor (NTC) on the main board in the module has failed (open circuit).

The resistance across the temperature compensation sensor (NTC) on the main board is dependent on ambient temperature. The change in resistance is used by the leak circuit to compensate for ambient temperature changes. If the resistance across the sensor increases above the upper limit, the error message is generated.

Probable cause

- 1 Defective main board.

Suggested actions

- Exchange the main board.

Compensation Sensor Short

The ambient-compensation sensor (NTC) on the main board in the module has failed (short circuit).

The resistance across the temperature compensation sensor (NTC) on the main board is dependent on ambient temperature. The change in resistance is used by the leak circuit to compensate for ambient temperature changes. If the resistance across the sensor falls below the lower limit, the error message is generated.

Probable cause

- 1 Defective main board.

Suggested actions

- Exchange the main board.

Left Fan Failed

The left cooling fan in the column compartment has failed.

The hall sensor on the fan shaft is used by the TCC board to monitor the fan speed. If the fan speed falls below 2 revolutions/second for longer than 5 seconds, the error message is generated.

Probable cause	Suggested actions
1 Fan cable disconnected.	Ensure the fan is connected correctly.
2 Defective fan.	Exchange fan.
3 Defective TCC board.	Exchange the TCC board.

Right Fan Failed

The right cooling fan in the column compartment has failed.

The hall sensor on the fan shaft is used by the TCC board to monitor the fan speed. If the fan speed falls below 2 revolutions/second for longer than 5 seconds, the error message is generated.

Probable cause	Suggested actions
1 Fan cable disconnected.	Ensure the fan is connected correctly.
2 Defective fan.	Exchange the fan.
3 Defective TCC board.	Exchange the TCC board.

Open Cover

The top foam has been removed.

The sensor on the TCC board detects when the top foam is in place. If the foam is removed, the fan is switched and peltier elements are switched OFF, and the error message is generated.

Probable cause	Suggested actions
1 The top foam was removed during operation.	Reinstall the top foam.
2 Foam not activating the sensor.	Exchange the foam.

Cover Violation

The column compartment was switched on with the top cover and foam open.

The sensor on the CCM board detects if the top foam is in place. If the column compartment is switched on with the foam removed, the processor switches OFF the peltier elements after a short delay, and the error message is generated.

Probable cause

- 1** The column compartment was switched on with the top cover and foam removed.

Suggested actions

Reinstall the top cover and foam.

Left Temperature Timeout

The temperature of the left heat exchanger did not reach the temperature setpoint within the timeout threshold.

Probable cause

- 1** Timeout threshold too short.
- 2** Defective left heater assembly.
- 3** Defective TCC board.

Suggested actions

Increase the timeout threshold value.

Exchange the heater assembly.

Exchange the TCC board.

Right Temperature Timeout

The temperature of the right heat exchanger did not reach the temperature setpoint within the timeout threshold.

Probable cause

- 1** Timeout threshold too short.
- 2** Defective right heater assembly.
- 3** Defective TCC board.

Suggested actions

Increase the timeout threshold value.

Exchange the heater assembly.

Exchange the TCC board.

Defective Temperature Sensor

One of the temperature sensors has failed.

The TCC board monitors the signal from the sensor continually. If the signal is missing or out of range, the error message is generated.

Defective Temperature Sensor 0: left column.

Defective Temperature Sensor 1: left heat sink.

Defective Temperature Sensor 2: right column.

Defective Temperature Sensor 3: right heat sink.

Defective Temperature Sensor 4: ambient-correction sensor (located on left flex board).

Probable cause

Suggested actions

- | | |
|--|---|
| 1 Flex board not connected (only if all left or right sensor error messages appear simultaneously). | Ensure the flex board is connected correctly. |
| 2 Defective heater assembly. | Exchange the heater assembly. |
| 3 Defective TCC board. | Exchange the TCC board. |

Heater Profile

Heater Profile 0: left heater.

Heater Profile 2: right heater.

The temperature warm-up (or cooling) profile of the heater is incorrect.

When the temperature setpoint is changed, the heater begins heating (or cooling) the column heat exchanger. During this time, the processor monitors the temperature change, and checks if the temperature profile is changing in the correct direction. If the temperature is not changing as expected, the error message is generated.

Probable cause

- 1 Defective heater assembly.
- 2 Defective TCC board.

Suggested actions

- Exchange the heater assembly.
- Exchange the TCC board.

Valve Failed

Valve Failed 0: failed to switch to the position where ports 1 and 2 are connected.

Valve Failed 1: failed to switch to the position where ports 1 and 6 are connected.

The column-switching valve failed to switch.

The switching of the column-switching valve is monitored by two micro switches on the valve assembly. The switches detect the successful completion of the valve movement within a predefined time window. If the valve fails to reach the end point, or fails to reach the end point within the time window, the error message is generated.

Probable cause

- 1 Defective column-switching valve.
- 2 Defective TCC board.

Suggested actions

- Exchange the column-switching valve.
- Exchange the TCC board.

Column Temperature

The temperature of the column heat exchanger has exceeded the maximum limit.

Column Temperature 0: left heater.

Column Temperature 2: right heater.

For safety reasons, the maximum column heat-exchanger temperature is 105 °C. If an electronic failure occurs which causes the heater to heat continually, the current is switched off when the temperature exceeds 105 °C, and the error message is generated.

Probable cause

- 1** Defective heater assembly.
- 2** Defective TCC board.

Suggested actions

- Exchange the heater assembly.
- Exchange the TCC board.

Heatsink Temperature

The temperature of the Peltier heatsink has exceeded the maximum limit.

Heatsink Temperature 0: left heater.

Heatsink Temperature 2: right heater

The maximum temperature of the Peltier heatsink is 70 °C. If an electronic failure occurs which causes the heatsink to reach 70 °C, the current is switched OFF and the error message is generated.

Probable cause

- 1** Defective heater assembly.
- 2** Defective TCC board.

Suggested actions

- Exchange the heater assembly.
- Exchange the TCC board.

Defective Heater Circuit

The electronic circuit for control of the heater assemblies is defective.

The processor checks the function of the heater circuits continually. If a defect is detected in the control circuit, the processor switches OFF the heater (peltier) assemblies, and the error message is generated.

Probable cause	Suggested actions
1 Defective TCC board.	Exchange the TCC board.

Valve failed to initialize (2875)

During initialization, the valve actuator turns until the encoder reads the reference index position. An error is generated, if the reference index cannot be found within a given time.

Probable cause	Suggested actions
1 Defect in cable connection of valve drive control.	Check cable connection to valve drive control, replace cable.
2 Defect in cable connection of valve actuator encoder reader.	Check cable connection to valve actuator encoder reader, replace cable.
3 Defect of valve drive or valve actuator encoder reader.	Replace Actuator Valve 5067-4106 .

Unknown/Unsupported Valve detected (2872)

After powering on, the RFID tag of the valve head is read out. An error is generated, if the RFID tag does not contain valid information. The RFID can be damaged if the instrument is power cycled during a write access of the tag.

Probable cause	Suggested actions
1 RFID tag contains invalid information.	Replace valve head, see Table 11 on page 178

Door sensor HW failure (2873)

This error is generated, if a front door is detected while the front door sensor has been disabled during the self-test.

Probable cause	Suggested actions
1 Defect in cable connection of door sensor to main board.	Check cable connection between door sensor and main board.
2 Door sensor defective.	Replace door sensor G1316-81603, see “Replacing the Door Sensor (G1316C SL Plus)” on page 174.

Valve RFID access failure (2874)

The valve tag reader fails reading or writing the RFID tag of the valve head.

Probable cause	Suggested actions
1 Defect in cable connection of valve tag reader to main board.	Check cable connection between valve tag reader to main board.
2 Valve head not installed correctly.	Review installation of valve head, see “Installing Valve Heads (G1316C SL Plus)” on page 42.
3 RFID tag defective.	Replace valve head, see Table 11 on page 178.
4 Valve tag reader is damaged.	Replace Actuator Valve 5067-4106 .



7 Test Functions

Thermostat Function Test	76
Pressure Test	79
Column Thermostat Temperature Calibration	80
Column Thermostat Temperature Calibration Procedure	82
Column Thermostat Calibration Problems	83
Installing the Temperature Sensor	83

This chapter describes the TCC's built in test functions.



Thermostat Function Test

Heater Function Test Description

The heater function test is used to evaluate the cooling and heating performance of the two peltier elements.

When the test is started, both heat exchangers are cooled initially to 25 °C. This temperature is held for 12 seconds, and then the setpoint is changed to 20 °C. The time required to reach 20 °C is a measure of the cooling efficiency of the peltier elements. At 3.5 minutes, the setpoint is changed to 30 °C, and both elements begin heating. The time required to reach 30 °C is a measure of heating efficiency.

Heater Function Test

Thermostat Function Test Result

A typical thermostat function test profile is shown in [Figure 19](#) on page 77.




Figure 19 Typical Thermostat Function Test Profile

Evaluating the Thermostat Function Test

During the cooling phase, the Peltier elements should cool at a rate of >2 °C/minute. During the heating phase, the temperature change should be >3 °C/minute. Defective thermostat components may cause cooling or heating rates to fall outside these limits.

Function Test Failed

Probable Causes

- Column compartment cover not installed correctly (bad insulation).
- Air intake blocked (insufficient air flow for cooling).
- Poor peltier efficiency (if setpoint temperatures can still be reached, and are stable, there is no requirement to exchange the heater assembly).
- Defective sensors on flex board.
- Defective heater assembly.

Suggested Actions

- ✓ Ensure cover is installed correctly.
- ✓ Ensure sufficient space is available for air circulation see “[Bench Space](#)” on page 26.
- ✓ Exchange the heater assembly.

Pressure Test

For running a pressure test, please refer to the corresponding pump manual. The pressure test may be used for testing the tightness of a valve installed in the TCC.

CAUTION

Wrong use of pressure test may damage valve.

The current implementation of the pressure test automatically uses the maximum pressure generated by the pump used by that system.

- Do not use the test for modules having a lower maximum pressure than the pump as this will damage the valve. For example do not use 400 bar valve in a TCC in combination with a 600 bar pump.
-

Column Thermostat Temperature Calibration

Temperature Calibration Principle

The actual temperatures of the column heat exchangers (left and right) depend on the column setpoint temperature. For setpoint temperatures above (36 °C), the heat exchangers are heated to a temperature slightly above the setpoint temperature. Conversely, for setpoint temperatures below (36 °C), the heat exchangers are kept at a temperature slightly below the setpoint temperature. This fine temperature correction compensates for the small amount of heat exchange through the instrument housing, and ensures the column is always kept at the setpoint temperature.

At (36 °C), the column setpoint and heat-exchanger temperatures are equal (temperature cross-over point). This is the temperature at which a calibrated measuring device can be used to calibrate the column thermostat.




Figure 20 1-Point Calibration at the Temperature Cross-Over Point

Column Thermostat Temperature Calibration

The column thermostat is calibrated correctly when the measured temperature (using the external measuring device, “[Column Thermostat Temperature Calibration Procedure](#)” on page 82) and the cross-over temperature (36 °C) of both heat exchangers (left and right) are within a range of ± 0.5 °C.

Column Thermostat Temperature Calibration Procedure

Tools required Temperature measuring device (see note below)

Parts required **Description**
Calibrated temperature measuring device

NOTE

For the measuring and calibration process Agilent Technologies recommends a thermometer with 0.1 °C precision. Contact the local Agilent Technologies support representative for ordering information.

NOTE

The figures in this procedure refer to a specific type of temperature sensor (Heraeus, Quat340, quartz surface-temperature measurement sensor). Other sensors may require a different fixing.

- 1 Install the temperature sensor (“[Installing the Temperature Sensor](#)” on page 83).
- 2 Select the column-compartment temperature calibration mode in the user interface.
- 3 Wait for the temperature to stabilize at the calibration temperature (36 °C).
- 4 Measure the temperature of the heat exchanger.
- 5 If the measured temperature deviates by more than ± 0.5 °C from the actual temperature, enter the measured value in the measured-temperature field for the left heat exchanger.
- 6 Install the sensor at the measurement point on the right heat exchanger. Repeat the calibration procedure for the right heat exchanger.

NOTE

Limits

After calibration, the measured temperature and the calibration temperature should be within ± 0.5 °C. The maximum deviation which can be adjusted is ± 1.6 °C. If the measured value and the calibration value differ by more than ± 1.6 °C, this is an indication that a problem exists, “[Column Thermostat Calibration Problems](#)” on page 83.

Column Thermostat Calibration Problems

If the temperature cannot be calibrated, check the following:

- Has the thermostat front cover been closed correctly?
- Is the measuring device functioning correctly, and is calibrated according to the manufacturers instructions.

Hardware Failures

Probable hardware failures that can lead to a failed calibration procedure are:

- Defective or wrongly calibrated measuring device.
- Defective heater assembly.
- Defective ambient-temperature sensor.
- Defective CCM board.

Installing the Temperature Sensor

Installation of the temperature sensor is required for the temperature calibration and temperature verification procedures.


NOTE

The figures below refer to a specific type of temperature sensor (Heraeus, Quat340, quartz surface-temperature measurement sensor). Other sensors may require a different fixing.


7 Test Functions

Column Thermostat Temperature Calibration


1 Remove the front cover.




2 Install the temperature sensor at the measurement position on the left heat exchanger.



3 Route the sensor wire through the slit in the leak tray.



4 Re-install the front cover.





8 Maintenance

Introduction to Maintenance and Repair	86
Warnings and Cautions	87
Overview of Maintenance	89
Cleaning the Column Compartment	90
Changing Column Identification Tags	91
Replacing Head Parts of Column Switching Valve (G1316A/G1316B SL)	93
Adding Heater and Cooling Devices (G1316B SL/G1316C SL Plus)	96
Correcting Leaks	99
Replacing the Column Compartment's Firmware	100
Replacing Valve Heads (G1316C SL Plus)	101
Preparing the G1316C SL Plus for Transportation	104

This chapter describes the maintenance of the TCC.



Introduction to Maintenance and Repair

Simple Repairs

The column compartment is designed for easy repair. The most frequent repairs such as change of column and column switching valve head parts can be done from the front of the column compartment without removing the TCC from the HPLC stack. These repairs are described in “[Maintenance](#)” on page 85.

Exchanging Internal Parts

Some repairs may require exchange of defective internal parts. Exchange of these parts requires removing the column compartment from the stack, removing the covers, and disassembling the column compartment. The security lever at the power input socket prevents that the column compartment cover is taken off when line power is still connected.

These repairs are described in “[Repair](#)” on page 107.

Warnings and Cautions

WARNING

Module is partially energized when switched off, as long as the power cord is plugged in.

Risk of stroke and other personal injury. Repair work at the module can lead to personal injuries, e. g. shock hazard, when the module cover is opened and the instrument is connected to power.

- Never perform any adjustment, maintenance or repair of the module with the top cover removed and with the power cord plugged in.
 - The security lever at the power input socket prevents that the module cover is taken off when line power is still connected. Never plug the power line back in when cover is removed.
-

WARNING

Sharp metal edges

Sharp-edged parts of the equipment may cause injuries.

- To prevent personal injury, be careful when getting in contact with sharp metal areas.
-

WARNING

Toxic and hazardous solvents

The handling of solvents and reagents can hold health risks.

- When working with solvents observe appropriate safety procedures (for example, goggles, safety gloves and protective clothing) as described in the material handling and safety data sheet supplied by the solvent vendor, especially when toxic or hazardous solvents are used.
-

8 Maintenance


Warnings and Cautions

CAUTION

Electronic boards and components are sensitive to electrostatic discharge (ESD). ESD can damage electronic boards and components.

- In order to prevent damage always use ESD protection when handling electronic boards and components.
-

CAUTION

Hot heat exchangers 

The column compartment has two heat exchanger assemblies that might be hot.

- Allow them to cool down before starting repairs.
-

Overview of Maintenance

The following pages describe maintenance procedures (simple repairs) that can be done without opening the main cover.

Table 6 Simple Repairs

Procedure	Typical Frequency	Notes
"Changing Column Identification Tags" on page 91	When column performance or new application requires a change	
"Replacing Head Parts of Column Switching Valve (G1316A/G1316B SL)" on page 93	If the valve performance shows indication of leakage or wear	
"Correcting Leaks" on page 99	If a leak has occurred	Check for leaks

Cleaning the Column Compartment

The column compartment case should be kept clean. Cleaning should be done with a soft cloth slightly dampened with water or a solution of water and a mild detergent. Make sure not to let liquid drip into your module.

WARNING

Liquid dripping into the electronic compartment of your module.

Liquid in the module electronics can cause shock hazard and damage the module.

- Do not use an excessively damp cloth during cleaning.
 - Drain all solvent lines before opening any fittings.
-

Changing Column Identification Tags

The column compartment is equipped with an column-identification system, that stores column specific information. Two identification antennas are incorporated in the heat exchanger assemblies.




Figure 21 Column-Identification System

When If column is used on the opposite heat exchanger or a tag is added to a new column.

Parts required	#	Part number	Description
	1	5062-8588	Column identification tag, pack of 3

- 1 The identification tag can be easily removed from the column.
- 2 The tag needs to be placed differently, depending on whether the column is installed at the left or right heat exchanger, see [Figure 15](#) on page 49 and [Figure 16](#) on page 50. The Agilent logo should always be at front.

When correctly placed on the heat exchanger, the distance between tag and antenna is 1–2 mm. This is the optimum distance for proper function.

8 Maintenance

Changing Column Identification Tags




Figure 22 Column-Identification Tag for Left Heat Exchanger




Figure 23 Column-Identification Tag for Right Heat Exchanger

- 3 For columns with small diameter, a cable tie wrap should be used to fix the column identification tag to the column. Assure that the tie wrap does not block the front cover.

Replacing Head Parts of Column Switching Valve (G1316A/G1316B SL)





Figure 24 Column Switching Valve Parts


When	If valve leaks.
Tools required	1/4 inch wrench 9/64 inch hex key
Parts required	Description For parts refer to “Valve Options Overview” on page 178.
	1 Remove capillaries from ports 1, 5, and 6.

8 Maintenance

Replacing Head Parts of Column Switching Valve (G1316A/G1316B SL)



- 2 Loosen each fixing stator screw two turns at a time. Remove bolts from head.



- 3 Remove the stator head and the ceramic stator face.

NOTE

Valve Head, 8 Position/9 Port, High Pressure **part number: 5067-4107** has no stator face.

- 4 Remove the stator ring.
- 5 Remove the rotor seal (and isolation seal if damaged or contaminated).
- 6 Install the new isolation seal (if required). Ensure the metal spring inside the ring faces towards the valve body.
- 7 Install the new rotor seal.
- 8 Replace the stator ring. Ensure the stator ring is flush with the valve body.
- 9 Place the new (if required) ceramic stator face in place on the stator head. Reinstall the stator head.

Replacing Head Parts of Column Switching Valve (G1316A/G1316B SL)

NOTE

Valve Head, 8 Position/9 Port, High Pressure **part number: 5067-4107** has no stator face.

10 Insert the stator screws in the stator head. Tighten the screws alternately two turns at a time until the stator head is secure.

11 Reconnect the pump capillaries to the valve ports. Slide the waste tube into the waste holder in the leak tray.

CAUTION

Wrong use of pressure test may damage valve.

The current implementation of the pressure test automatically uses the maximum pressure generated by the pump used by that system.

→ Do not use the test for modules having a lower maximum pressure than the pump as this will damage the valve. For example do not use 400 bar valve in a TCC in combination with a 600 bar pump.

12 Perform a pressure-tightness test to ensure the valve is pressure tight to 400 bar.

Adding Heater and Cooling Devices (G1316B SL/G1316C SL Plus)

The additional heater and cooling devices can be arranged in the G1316B SL/G1316C SL Plus in various locations depending on the application needs. Some examples are shown below.




Figure 25 Arrangements of Heater and Cooling Devices (G1316B SL/G1316C SL Plus)

NOTE

If the additional heater and cooling devices are used as shown above, the column identification system cannot be used. If the column identification system is required, fix the heater and cooling devices in the upper or lower locations or fix them right/left of the current location.

The heater and cooling devices are mounted on a carrier that can be fitted to the left and/or right heat exchangers.

Fixing Heater or Cooling Devices (G1316B SL)




Figure 26 Fixing Heater or Cooling Devices (G1316B SL)

Fixing the Low Dispersion Heat Exchangers (G1316C SL Plus)

For the G1316C SL Plus, additional heat exchanger and cooling devices can be installed on the carrier **part number: G1316-89200** using 3 screws (**part number: 0515-1052**, included to part number for carrier) as shown in figure below.

8 Maintenance

Adding Heater and Cooling Devices (G1316B SL/G1316C SL Plus)





Figure 27 Installing the low dispersion heat exchangers

Choose Compatible Fittings


For the heater device inlet capillary choose fittings which are compatible to your column.

Swagelock compatible columns (5065-4454, pk of 10, with ferrules)



Fitting screw long

Swagelock compatible columns, removable (0100-2086)



Nut seal tight

Figure 28 Fitting type depends on column type

Correcting Leaks

When If a leakage has occurred at the heat exchanger or at the capillary connections or at the column switching valve.

Tools required Tissue, pipette
Wrench 1/4 – 5/16 inch for capillary connections

NOTE

Depending on the column position or the use of additional heat-exchanger assemblies, the view of [Figure 29](#) on page 99 may vary.

- 1 Remove the front cover.
- 2 Use a pipette and tissue to dry the leak sensor area.
- 3 Observe the capillary connections and the column switching valve for leaks and correct, if required.
- 4 Re-install the front cover.




Figure 29 Possible Leak Areas

Replacing the Column Compartment's Firmware

The installation of *older* firmware might be necessary:

- to keep all systems on the same (validated) revision, or
- if third part control software requires a special version.

To upgrade/downgrade the TCC's firmware the following steps have to be performed:

When	If new version solves problems of currently installed version or after exchange of the TCC main board (CCM) the version on board is older than previous installed one.
Tools required	LAN/RS-232 Firmware Update Tool, or Instant Pilot G4208A or Control Module G1323B
Parts required	Description Firmware, tools and documentation from Agilent web site
Preparations	Read update documentation provided with the Firmware Update Tool. <ol style="list-style-type: none">1 Download the module's firmware, the LAN/RS-232 FW Update Tool Version 2.10 or above and the documentation from the Agilent web http://www.chem.agilent.com/scripts/cag_firmware.asp.2 Load the firmware into the TCC as described in the documentation.

NOTE The G1316B SL requires firmware revision A.06.02 or higher (main and resident).
The G1316C SL Plus requires firmware revision A.06.10 or higher (main and resident).

Replacing Valve Heads (G1316C SL Plus)

Several optional valve heads are available for the G1316C, which can be installed and exchanged easily.

Parts required	#	Part number	Description
	1	5067-4107	8pos/9prt valve head high pressure and/or
	1	5067-4108	8pos/9prt valve head low pressure

CAUTION

Valve Damage

Using a low pressure valve on the high pressure side can damage the valve.

- When using multiple column compartments as part of a method development solution, make sure that the high pressure valve head is connected to the autosampler and the low pressure valve head is connected to the detector.
- For details, please refer to the Method Development Solution User and Installation Guide (**part number: G4230-90000**).

CAUTION

Column Damage or Bias Measurement Results

Switching the valve to a wrong position can damage the column or bias measurement results.

- Fitting the lobe to the groove is essential for making sure the valve is switched to the correct position.

CAUTION

Valve properties are read from the valve head RFID tag during initialization of the module. Valve properties will not be updated, if the valve head is replaced while the module is on.

Selection of valve port positions can fail, if the instrument does not know the properties of the installed valve.

- Always switch off the instrument when replacing the valve head.

8 Maintenance

Replacing Valve Heads (G1316C SL Plus)


CAUTION

The valve actuator contains sensitive optical parts, which need to be protected from dust and other pollutions. Pollution of these parts can impair the accurate selection of valve ports and therefore bias measurement results.

→ Always install a valve head for operation and storage. For protecting the actuator, a dummy valve head (part of transportation lock kit **part number: G1316-67001**) can be used instead of a functional valve. Do not touch parts inside the actuator.


- 1 Switch off the module.
- 2 Push the valve head for bringing it to its outer position and unscrew all capillary connections from the valve head.

- 3 Unscrew the valve head.




Replacing Valve Heads (G1316C SL Plus)


4 Put the new valve head onto the valve drive such that the lobe fits to the groove.




5 Screw the valve head onto the valve drive using the union nut.



6 Install all required capillary connections to the valve head



7 Push the valve head until it snaps in and stays in the rear position.



8 Switch on the module.

8 Maintenance

Preparing the G1316C SL Plus for Transportation

Preparing the G1316C SL Plus for Transportation

When If the Thermostatted Column Compartment SL Plus G1316C shall be transported


Tools required Screwdriver Pozidriv 1 PT3

Parts required	#	Part number	Description
	1	G1316-67001	Transportation Lock Kit

The module has been shipped with transportation locks, which must be used for transportation protection. A transportation lock kit can be re-ordered using


1 Remove the valve head as described in [“Replacing Valve Heads \(G1316C SL Plus\)”](#) on page 101.

2 Replace the valve head by the transportation valve head. Bring the transportation valve head to the outer position.




Preparing the G1316C SL Plus for Transportation

- 3** Use 4 screws M3x8 (**0515-0897**) for fixing the lock plate (**G1316-03701**) to the heat exchangers in the outer positions of the plate.




- 4** Use a screw (**2680-0128**) for fixing the lock plate to the transportation valve head (**G1316-40002**) in the central position of the plate.



8 Maintenance

Preparing the G1316C SL Plus for Transportation



9 Repair

Cautions and Warnings	108
Removing the Top Cover and Foam	110
Removing a Valve	114
Installing a Valve	119
Exchanging the Main Board	124
Changing the Type and Serial Number	129
Recover Instructions	134
Exchanging the Fan	138
Removing the Heat Exchanger Assemblies	140
Installing the Heat Exchanger Assemblies	145
Exchanging the Power Supply	152
Replacing the Leak Sensor or Leak Base (G1316A/G1316B SL)	156
Replacing Status Light Pipe	161
Installing the Foam and the Top Cover	162
Assembling the Main Cover	168
Installing the Radio Frequency Shield (G1316C SL Plus)	170
Installing the leak sensor (G1316C SL Plus)	172
Replacing the Door Sensor (G1316C SL Plus)	174

This chapter gives instructions on how to repair the TCC.



Cautions and Warnings

WARNING

Sharp metal edges

Sharp-edged parts of the equipment may cause injuries.

- To prevent personal injury, be careful when getting in contact with sharp metal areas.
-

WARNING

When opening capillary or tube fittings solvents may leak out.

The handling of toxic and hazardous solvents and reagents can hold health risks.

- Please observe appropriate safety procedures (for example, goggles, safety gloves and protective clothing) as described in the material handling and safety data sheet supplied by the solvent vendor, especially when toxic or hazardous solvents are used.
-

WARNING

Module is partially energized when switched off, as long as the power cord is plugged in.

Risk of stroke and other personal injury. Repair work at the module can lead to personal injuries, e. g. shock hazard, when the module cover is opened and the instrument is connected to power.

- Never perform any adjustment, maintenance or repair of the module with the top cover removed and with the power cord plugged in.
 - The security lever at the power input socket prevents that the module cover is taken off when line power is still connected. Never plug the power line back in when cover is removed.
-

NOTE

The electronics of the column compartment will not allow operation of the module when the top cover and the top foam are removed. A safety light switch on the main board will inhibit the operation of the fans immediately. Voltages for the other electronic components will be turned off after 30 seconds. The status lamp will light red and an error will be logged into the logbook of the user interface. Always operate the column compartment with the top covers in place.

CAUTION

Electronic boards and components are sensitive to electrostatic discharge (ESD). ESD can damage electronic boards and components.

→ In order to prevent damage always use ESD protection when handling electronic boards and components.

CAUTION

Hot heat exchangers 

The column compartment has two heat exchanger assemblies that might be hot.

→ Allow them to cool down before starting repairs.

9 Repair

Removing the Top Cover and Foam


Removing the Top Cover and Foam

When For all repairs inside the column compartment

Tools required Screwdriver Pozidriv 1 PT3


Parts required	#	Part number	Description
	1	G1316-68714	Front cover G1316A
	1	G1316-68724	Front cover G1316B SL
	1	G1316-68754	Front Cover G1316C SL Plus
	1	G1316-68713	Plastic kit G1316A/G1316B SL
	1	G1316-68723	Plastik Cover Kit G1316C SL Plus
	1	G1316-68702	Foam parts G1316A/G1316B SL
	1	G1316-68712	Foam parts G1316C SL Plus

- Preparations**
- Turn OFF the column compartment.
 - Disconnect the power cable.
 - Disconnect capillaries.
 - Remove column compartment from stack and place it on the working bench.




Removing the Top Cover and Foam


3 Move the power lock across the power inlet and lift the clips on the rear of the cover.




4 Lift the cover up and slide it towards the rear.



5 Unscrew the screws at the rear of the top plate, slide the plate towards the front and remove it.



6 If installed, disconnect the connector of the column switching valve from column compartment (G1316A/G1316B SL).




9 Repair

Removing the Top Cover and Foam

- 7** For G1316C, remove the cables of the valve tag reader, valve actuator encoder reader, valve actuator drive control and door sensor.

Valve actuator encoder reader


Door sensor



Valve tag reader

Valve actuator drive control


- 8** Remove the top foam.




NOTE

Do not connect a power plug to the column compartment after removing the top covers.
A safety light switch on the main board will turn OFF fan (immediately) and electronics (after 30 seconds) to avoid the operation with removed covers. An error will be generated (status lamp lights red) and the logbook will show an error message

- 9** Position of the foam in the safety light switch.



10 Position of safety light switch on the main board when removing the foam.



Removing a Valve

Removing a Valve from the Thermostatted Column Compartment (G1316A/G1316B SL)


When If valve failed or bottom foam part has to be removed for other replacements

Tools required Screwdriver Pozidriv 1 PT3
Wrench 1/4 – 5/16 inch for capillary connections


Preparations

- Turn OFF the column compartment.
- Disconnect the power cable.
- Disconnect capillaries.
- Remove column compartment from stack and place it on the working bench.
- Remove the front cover, top cover and top foam section, see [“Removing the Top Cover and Foam”](#) on page 110.


1 Disconnect the grounding connection of the valve at the Z-panel.




2 Unscrew the Z-panel.




3 Press against the rear of the Z-panel to release the metal plate from the guide and pull it carefully upwards.




4 Lift the Z-panel together with the top plastic panel several centimeters out of the guide, then ...



5 ... locate the ambient temperature sensor in the top plastic part and push it towards the rear.




6 Carefully remove the ambient temperature sensor plugged into the rear of the top plastic panel.




9 Repair

Removing a Valve

7 Pull the top plastic panel together with the Z-panel completely out of the guide.



8 Remove the Valve from its location.



NOTE

For the installation refer to [“Installing a Valve \(G1316A/G1316B SL\)”](#) on page 119.


Removing the sliding unit (G1316C SL Plus)

When If valve actuator or sliding unit need to be replaced.

Preparations

- Turn OFF the column compartment.
- Disconnect the power cable.
- Disconnect capillaries.
- Remove column compartment from stack and place it on the working bench.
- Remove the front cover, top cover and top foam section.

- 1 Push the valve head such that it snaps in at its rear position.
- 2 Lift up the sliding unit at the rear.



- 3 Carefully remove the sliding unit from the bottom foam part and pull it out of the valve liner.

NOTE

If the thermostatted column compartment shall be operated without valve and sliding unit, the opening must be closed using an radio frequency shield and the valve cover in order to avoid radio frequency emission from the module, see [“Installing the Radio Frequency Shield \(G1316C SL Plus\)”](#) on page 170

9 Repair

Removing a Valve


Replacing the Valve Actuator (G1316 C SL Plus)

When If the valve actuator shall be replaced.

Parts required	#	Part number	Description
	1	5067-4106	Actuator Valve

Preparations Remove the sliding unit from the bottom foam part (“[Removing the sliding unit \(G1316C SL Plus\)](#)” on page 117).

- 1 Slightly expand the metal housing of the sliding unit (1), twist out the valve actuator (2) and lift it out (3) of the sliding unit.



Installing a Valve

Installing a Valve (G1316A/G1316B SL)

When	For first time installation or after it was removed
Tools required	Screwdriver Pozidriv 1 PT3 Wrench 1/4 – 5/16 inch for capillary connections
Preparations	Open the column compartment as described in “Removing a Valve from the Thermostatted Column Compartment (G1316A/G1316B SL)” on page 114.

CAUTION

The flexible cables close to the heat exchanger assemblies may be easily damaged.

- Be careful that the flexible cables close to the heat exchanger assemblies are not damaged, especially during steps 3 through 6.
-

CAUTION


The ambient temperature sensor may be damaged if incorrectly installed.

- Ensure that the ambient temperature sensor is completely plugged into the rear of the top plastic panel.
-


9 Repair

Installing a Valve


1 If no column valve is installed, remove the RFI-shield and the plastic cover (no longer used).




2 Replace the valve into its location.




3 Carefully insert the top plastic panel together with the Z-panel into the guide and press it half-way down.




4 Carefully plug the ambient temperature sensor into the rear of the top plastic panel.




5 Press the Z-panel together with the Top Plastic Panel completely down.




6 Press down completely until it clicks into its holding position.



7 Fix the Z-panel with the two screws.



8 Reconnect the grounding connection of the valve at the Z-panel.



9 Repair

Installing a Valve

Next Steps:

- 9 Reinstall the foam section, the top cover and front cover, see [“Installing the Foam and the Top Cover \(G1316A/G1316B SL\)”](#) on page 162.
- 10 Place the column compartment back into stack and reconnect capillaries and the power cable.
- 11 Turn ON the column compartment.


Installing the sliding unit (G1316C SL Plus)

When If a new sliding unit or valve actuator shall be installed.


Parts required	#	Part number	Description
	1	G1316-60000	Sliding Unit

Preparations Make sure, that the leak sensor has been installed correctly (“[Installing the leak sensor \(G1316C SL Plus\)](#)” on page 172).

1 Insert the valve liner.



2 Insert the sliding unit to the valve liner and push down the sliding unit such that it fits properly to the bottom foam part.



NOTE

Before connecting the valve actuator to the main board, install the top foam (“[Installing the Top Cover and Foam \(G1316C SL Plus\)](#)” on page 165).

Exchanging the Main Board

Exchanging the Main Board (G1316A/G1316B SL)

When If board is defective or for repair of other assemblies

Tools required Screwdriver Pozidriv 1 PT3
Hexagonal wrench 5 mm

Parts required

#	Part number	Description
1	G1316-69540	Main board CCM (exchange assembly) for G1316A/G1316B SL for Series 1200.


Preparations

- Turn OFF the column compartment.
- Disconnect the power cable.
- Disconnect capillaries.
- Remove column compartment from stack and place it on the working bench.
- Remove the front cover, top cover and top foam section, see “[Removing the Top Cover and Foam](#)” on page 110.

NOTE


The Agilent 1200 Series G1316A/G1316B SL no longer has a GPIB connection

- 1 Use a 5 mm wrench to unscrew the REMOTE connector.



2 Disconnect all connectors from the processor board.

- J2 - RS-232C
- J3 - REMOTE
- J5/25 - CAN
- J7 - Power Supply
- J11 - Column Switching Valve
- J14 - Heat Exchanger Assembly (left)
- J15 - Heat Exchanger Assembly (right)
- J16 - Fan Assembly (right)
- J17 - Fan Assembly (left)
- J18 - Leak Sensor
- J19 - Flexboard (left)
- J21 - Flexboard (right)
- B - Battery
- S - Configuration Switch



- 3** Remove the processor board. Place the board on the ESD kit.
- 4** In some cases the RFI spring plate may remain on the interface connectors of the board. Carefully remove the spring plate and place it back into its position in the instrument before installing a new board.
- 5** On the new board check the switch setting of address switch S1, see [“Setting the 8-bit Configuration Switch”](#) on page 239.

NOTE

An incorrect switch setting (e.g., TEST/BOOT) may cause the module to turn in a basic mode (yellow or red flashing status light). In such a case turn off the module, re-set the address switches, and turn on the module again.

- 6** Install the new processor board and reconnect the connectors.
- 7** Refit the screws at the REMOTE connectors.
- 8** Reinstall the foam section, the top cover and front cover, see [“Installing the Foam and the Top Cover \(G1316A/G1316B SL\)”](#) on page 162.
- 9** Reinstall the column compartment into the stack and reconnect the cables.

NOTE

If a new CCM board is installed, update the serial number information of the column compartment in the user interface [“Introduction”](#) on page 129.

9 Repair

Exchanging the Main Board

- 10 Check the firmware revision of the module. If the firmware revision is older than the current firmware revision of the module, update the firmware using the standard firmware update procedure, see [“Replacing the Column Compartment’s Firmware”](#) on page 100.

Exchanging the Main Board (G1316C SL Plus)

When When board is defective or for repair of other assemblies


Tools required Screwdriver Pozidriv 1 PT3
Hexagonal wrench 5 mm

Parts required	#	Part number	Description
	1	G1316-61050	Main board CCM for G1316C SL Plus.


Preparations

- Turn OFF the column compartment.
- Disconnect the power cable.
- Disconnect capillaries.
- Remove column compartment from stack and place it on the working bench.
- Remove the front cover, top cover and top foam section, see [“Removing the Top Cover and Foam”](#) on page 110.

- 1 Use a 5 mm wrench to unscrew the REMOTE connector.



2 Disconnect all connectors from the processor board.



- 3** Remove the processor board. Place the board on the ESD kit.
- 4** In some cases the RFI spring plate may remain on the interface connectors of the board. Carefully remove the spring plate and place it back into its position in the instrument before installing a new board.
- 5** On the new board check the switch setting of address switch S1, see [“Setting the 8-bit Configuration Switch”](#) on page 239.

NOTE

An incorrect switch setting (e.g., TEST/BOOT) may cause the module to turn in a basic mode (yellow or red flashing status light). In such a case turn off the module, re-set the address switches, and turn on the module again.

- 6** Install the new processor board and reconnect the connectors.
- 7** Refit the screws at the REMOTE connectors.
- 8** Reinstall the foam section, the top cover and front cover, see [“Installing the Foam and the Top Cover \(G1316A/G1316B SL\)”](#) on page 162.
- 9** Reinstall the column compartment into the stack and reconnect the cables.

NOTE

If a new CCM board is installed, update the serial number information of the column compartment in the user interface [“Introduction”](#) on page 129.

9 Repair

Exchanging the Main Board

- 10 Check the firmware revision of the module. If the firmware revision is older than the current firmware revision of the module, update the firmware using the standard firmware update procedure, see [“Replacing the Column Compartment’s Firmware”](#) on page 100.

Changing the Type and Serial Number

Introduction

When the main board has to be replaced, the new board does not have a serial number. For some modules (e.g. pumps or auto samplers) the type has to be changed (multiple usage boards). Use the information from the serial number plate of your module.

Keep in mind that

- the changes become active after a power cycle of the module.
- the information from the serial number plate of the module is used.
- the exact type (product number) is used.

NOTE

If the type (product number) was entered incorrectly, the module may become unusable. Proceed to [“Overview”](#) on page 134.

NOTE

With firmware A.06.02/B.01.02 and above a wrong type cannot be entered. The entry is checked against the board revision.

Using the Agilent Diagnostic Software

The Agilent Diagnostic Software must be configured in Service Mode to have access to the function **Board Check and Change**.

Close other user interfaces.

- 1 Start the Diagnostic Software.
- 2 Select Tools on the left navigation panel.
- 3 Select in the Tools Selection box **Board Check and Change** and press the button **Start**.
- 4 Change the field Type and/or Serial as required.

NOTE

Some Agilent 1100/1200 series modules require the correct main board version to match the type, for example the SL modules.

- 5 Press the button **Apply** to complete the action.
A message "The type was changed to XXXXXX. Close this application and switch off and on the changed LC module.
- 6 Close the Diagnostic Software.
- 7 Power cycle the module.
- 8 Restart the User Interface.

Using the Agilent ChemStation

Module serial numbers are entered by typing specific commands on the command line at the bottom of the main user interface screen.

Turn the module on.

Start the Agilent ChemStation.

- 1 To enter a module serial number, type the following command into the command line:

```
print sendmodule$(Lxxx, "ser 'YYNNNNNNNNN' ")
```

 or

```
print sendmodule$(Nxxx, "ser 'YYNNNNNNNNN' ")
```

 where: xxx is the module type, YY is country code (in capital letters) and NNNNNNNN the 8-character serial number of the module in question.

Table 7 ChemStation Command Format - Serial Number Change

Modules with or without optional interface board	Modules with LAN on-board
PRINT SENDMODULE\$(Lxxx,"SER 'YYNNNNNNNNN'")	PRINT SENDMODULE\$(Nxxx,"SER 'YYNNNNNNNNN'")
module identifier = L serial number embedded in single-quotes	module identifier = N serial number embedded in single-quotes
PMP, ALS, THM, TCC, VWD, DAD, MWD, FLD, RID	DAD, MWD, VWD

NOTE

The first two characters are letters, which should be capitalized.

The reply line will respond with **RA 0000 SER** followed by the module serial number you just entered.

- 2 To change the type of the module use the following command:

```
print sendmodule$(Lxxx, "TYPE 'XXXXX' ")
```

or

```
print sendmodule$(Nxxx, "TYPE 'XXXXX' ")
```

where: xxx is the module type and XXXXX is the 5-character product number of the module (e.g. G1314B).

Table 8 ChemStation Command Format - Type Change

Modules with or without optional interface board	Modules with LAN on-board
PRINT SENDMODULE\$(Lxxx,"TYPE 'XXXXX'")	PRINT SENDMODULE\$(Nxxx,"TYPE 'XXXXX'")
module identifier = L product number XXXXX embedded in single-quotes	module identifier = N product number XXXXX embedded in single-quotes
PMP, ALS, THM, TCC, VWD, DAD, MWD, FLD, RID	DAD, MWD, VWD

NOTE

Some Agilent 1100/1200 series modules require the correct main board version to match the type, for example the SL modules.

- 3 Power cycle the module. Then, restart the Agilent ChemStation. If the serial number you have just entered is different than the original module serial number, you will be given the opportunity to edit the configure **1200 access** screen during the restart of the Agilent ChemStation.
- 4 After restart, the serial number/type you have just entered can be seen under the **Instrument** menu of the main user interface screen.

Using the Instant Pilot G4208A

- 1 Connect the Instant Pilot to the module. Turn ON the module.
- 2 On the Instant Pilot's Welcome screen, press **More**, then select **Maintenance**. Using the **up/down arrows**, select the module where you have to change the product number or serial number.
- 3 Press **PN/SN**. This will display a screen where you can enter the product number and/or serial number.
- 4 Make your changes, using the information from the product label of your module.

NOTE

Some Agilent 1100/1200 series modules require the correct main board version to match the type, for example the SL modules.

- 5 Press **OK** to highlight the complete command.
- 6 Press **Done** to transfer the information into the main board's memory. Press **Cancel** to quit the process.
- 7 Power cycle the module. The Maintenance screen should display the correct serial number for this module.
- 8 If an other User Interface is also connected, restart the User Interface as well.

Using the Control Module G1323B

- 1 Connect the control module to the module. Turn ON the module.
- 2 On the control module, press **System (F5)**, then **Records (F4)**. Using the **up/down arrows**, make sure that the module is highlighted.
- 3 Press **FW Update (F5)**, then **m**. This will display a box which says **Update Enter Serial#**.
- 4 Press **Enter**. This will display the box labeled **Serial#**.
- 5 Letters and numbers are created using the up and down arrows. Into the box labeled **Serial#**, enter the 10-character serial number for the module. When the 10-character serial number is entered, press **Enter** to highlight the complete serial number. Then, press **Done (F6)**.

- 6 Turn the module OFF then ON again. The Records screen should display the correct serial number for this module.
- 7 If a Agilent ChemStation is also connected, restart the Agilent ChemStation now as well.

NOTE

To change the product number go to the *System* screen.

- 8 Press **Tests** (F3) and select the module and press **Enter**.
- 9 While in the Tests screen, press **m.m** (m dot m).
- 10 From the box now displayed, select the *Command*, and press **Enter**.
- 11 Into the box labeled *Nester* (instruction), enter the command **TYPE 'XXXXXX'** where XXXXXX is embedded in single-quotes.

Letters and numbers are created using the up and down arrows. XXXXXX is the 5-character product number of the module being changed. There must be a space between the word TYPE and the product number.

NOTE

Some Agilent 1100/1200 series modules require the correct main board version to match the type, for example the SL modules.

- 12 Now, press the **Execute** key. Below the box, a reply line should then say:
Reply RA 0000 TYPE "XXXXXX" (XXXXXX is what you just entered)
- 13 Power cycle the module. Turn on should be normal. In the *Records* screen, the product# column should indicate the module you just entered. If an other User Interface is also connected, start it now.

Recover Instructions

Overview

The following situations may come up where the instrument is no longer usable due to

- an incorrect type (product number) entry after the replacement of a main board of the module.
- load of wrong firmware based on the wrong type.

NOTE

With firmware A.06.02/B.01.02 and above a wrong type cannot be entered. The entry is checked against the board revision.

The wrong type (product number) could be

- incorrect, but a valid 1100/1200 series module number
- incorrect and invalid 1100/1200 series module number (any name)

Based on above, the User Interfaces react differently.

Table 9 Recover From Wrong Type

User Interface	incorrect but valid type	incorrect but valid type	incorrect and invalid type
Example Conditions	correct type = G1315B entered type = G1314B	correct type = G1315B entered type = G1314B plus wrong firmware from G1314B	correct type = G1315B entered type = G1319B
ChemStation "Recover with Agilent Diagnostic Software (Type & Firmware)" on page 136	shows the incorrect product number Interface shows the settings of the G1314B Type can be changed via command line as described under "Recover with Agilent ChemStation" on page 136	does not show the module NO access to the module is possible Use "Recover with Agilent Diagnostic Software (Type & Firmware)" on page 136	does not show the incorrect product number NO access at all to the module is possible Use "Recover with Agilent Diagnostic Software (Type & Firmware)" on page 136

Table 9 Recover From Wrong Type

User Interface	incorrect but valid type	incorrect but valid type	incorrect and invalid type
Instant Pilot G4208A	comes up with an error access to the module is possible via Service Mode as described under “Recover with Instant Pilot” on page 136	shows resident module G1314B-R NO type change possible Use “Recover with Agilent Diagnostic Software (Type & Firmware)” on page 136	comes up with an error unsupported module G1319B access to the module is possible via Service Mode as described in “Recover with Instant Pilot” on page 136
Control Module G1323	comes up with an error NO access to the module is possible Use “Recover with Agilent Diagnostic Software (Type Only)” on page 135	shows resident or unsupported module NO type change possible Use “Recover with Agilent Diagnostic Software (Type & Firmware)” on page 136	shows resident or unsupported module access to the module is possible via Tests as described in “Recover with Control Module” on page 137
Agilent Diagnostic Software (preferred tool)	shows the incorrect product number access to the module is possible as described in “Recover with Agilent Diagnostic Software (Type Only)” on page 135	shows the incorrect product number access to the module is possible as described in “Recover with Agilent Diagnostic Software (Type Only)” on page 135 If wrong firmware has been loaded in addition, only the LMD Software can revert to correct product number as described in “Recover with Agilent Diagnostic Software (Type & Firmware)” on page 136	shows the incorrect product number access to the module is possible as described in “Recover with Agilent Diagnostic Software (Type Only)” on page 135

Recover with Agilent Diagnostic Software (Type Only)

The Diagnostic Softwares is used in CE mode.

If no LAN connection is possible use RS-232.

The example uses G1315B as correct type.

- 1 Open a connection to the module (or via system).

The module will be listed with the wrong product number (type).

- 2 Select Board Check and Change and press **Start**.
- 3 In the type field enter G1315B and press **Apply**.
- 4 Close the Agilent Diagnostic Software.
- 5 After a power cycle the module should show up with the correct product number (type) in the user interface.

Recover with Agilent Diagnostic Software (Type & Firmware)

Agilent Diagnostic Software in CE mode.

If no LAN connection is possible use RS-232.

The example uses G1315B as correct type.

The module must be configured to "*Stay Resident Mode*" (module boots in resident mode - flashing status LED).

- 1 Open a connection to the module (or via system).
- 2 Select Board Check and Change and press **Start**.
- 3 In the type field enter G1315B and press **Apply**.
- 4 After a power cycle the module should show up with the correct product number (type) in the user interface.
- 5 Load the correct main firmware into the module.
- 6 Turn the module OFF.
- 7 Set module's configuration switch back to normal mode.
- 8 Turn on the module.
- 9 If required, load final firmware into the module.

Recover with Agilent ChemStation

- 1 Use the ChemStation command line to change to TYPE (product number) as described under "[Using the Agilent ChemStation](#)" on page 130.

After power cycle of module the correct TYPE shows up.

Recover with Instant Pilot

USB Flash Drive with file CUSTINST.CMD and a PC with USB interface.

The example uses G1315B as correct type and G1319B as incorrect type.

- 1 Edit/create the file CUSTINST.CMD and add the following line
XXXXX|Command from USB 'Type Change'|TYPE 'YYYYYY'
where XXXXX is for example G1319 from the mis-typed G1319B and YYYYYY is the correct module type, e.g. G1315B.
- 2 Save and close the file.
- 3 Insert the USB Flash Drive into the Instant Pilot.
- 4 From the Welcome screen enter the Service Mode (7268312 or SERVICE).
- 5 Select the button G1319B (wrong module) and select
XXXXX|Command from USB 'Type Change'
- 6 Press the button **Send**.
This will give as reply:
RA 0 TYPE "G1315B"
- 7 After a power cycle the module should show up with the correct product number (type) in the user interface.

Recover with Control Module

The example uses G1315B as correct type.

- 1 Select **Tests** - Generic.
- 2 Press keys **m.m** (m dot m).
This opens hidden functions.
- 3 Select **Command**.
- 4 In the instruction line enter the command
TYPE G1315B

This will give as reply:
RA 0000 TYPE "G1315B"
- 5 After a power cycle the module should show up with the correct product number (type) in the user interface.

Exchanging the Fan

When If the fan is defective or noisy or for repair of other assemblies

Tools required Screwdriver Pozidriv 1 PT3

Parts required	#	Part number	Description
	1	3160-1017	Fan assembly

Preparations Turn OFF the column compartment.
Disconnect the power cable.
Disconnect capillaries.
Remove column compartment from stack and place it on the working bench.
Remove the front cover, top cover and top foam section, see "[Removing the Top Cover and Foam](#)" on page 110.


CAUTION

Incorrect positioning of fan might cause the thermostat to fail


Column compartment is not thermostatted correctly. Samples can degrade or measurement results can be biased due to wrong temperature.

→ Make sure the fan is installed in the correct orientation to ensure optimum cooling and operation of the column compartment.


1 Disconnect the fan assembly from the processor board.




2 Replace the fan assembly. Ensure correct fan orientation.



3 The arrow on the fan should correspond with the direction of air flow which is from the front to the rear of the column compartment.



4 Reconnect the fan assembly to the processor board and check that the cable of the left fan is correctly in the foam channel to assure correct closing of the foam parts.



5 Replace the foam part, the top cover and front cover, see [“Installing the Foam and the Top Cover \(G1316A/G1316B SL\)”](#) on page 162.

Removing the Heat Exchanger Assemblies

Removing the Heat Exchanger Assemblies (G1316A/G1316B SL)

When If the heater is leaking, blocked, does not heat/cool or if other assemblies have to be removed


Tools required Screwdriver Pozidriv 1 PT3
Wrench 1/4 – 5/16 inch for capillary connections

Parts required	#	Part number	Description
	1	G1316-60007	Heat exchanger assembly (left), includes ambient temperature sensor
	1	G1316-60006	Heat exchanger assembly (right)


Preparations

- Turn OFF the column compartment.
- Disconnect the power cable.
- Disconnect capillaries.
- Remove column compartment from stack and place it on the working bench.
- Remove the front cover, top cover and top foam section, see [“Removing the Top Cover and Foam”](#) on page 110.

1 Disconnect the heat exchanger cables from the processor board and the grounding connection of the column switching valve.




2 Carefully pull out the heater cables out of the foam channels.




Removing the Heat Exchanger Assemblies


3 Unscrew the Z-panel.




4 Press against the rear of the Z-panel to release the metal plate from the guide and pull it carefully upwards.



5 Lift the Z-panel together with the top plastic panel half-way out of the guide.




6 Locate the ambient temperature sensor in the top plastic part.




9 Repair
Removing the Heat Exchanger Assemblies


7 Carefully remove the ambient temperature sensor plugged into the rear of the top plastic panel.



8 Carefully pull out the top plastic panel together with the Z-panel completely.



9 Remove the heat exchanger assembly.



10 The repair level of the heat exchanger assemblies is the complete assembly.

Removing the Heat Exchanger Assemblies (G1316C SL Plus)

When If the heater is leaking, blocked, does not heat/cool or if other assemblies have to be removed


Tools required Screwdriver Pozidriv 1 PT3
Wrench 1/4 – 5/16 inch for capillary connections

Parts required	#	Part number	Description
	1	G1316-60007	Heat exchanger assembly (left), includes ambient temperature sensor
	1	G1316-60006	Heat exchanger assembly (right)


Preparations

- Turn OFF the column compartment.
- Disconnect the power cable.
- Disconnect capillaries.
- Remove column compartment from stack and place it on the working bench.
- Remove the front cover, top cover and top foam section, see [“Removing the Top Cover and Foam”](#) on page 110.

1 Remove the Z-Panel by opening 3 screws.




2 Disconnect the 4 heat exchanger cables from the processor board, which are 2 flexible board cables for the column tag reader and heat sensor and 2 power cables (each pair red/black) located below these cables.




9 Repair

Removing the Heat Exchanger Assemblies


3 On both sides of the valve actuator, there are fixation clips which keep the flexible boards of the heat exchanger assemblies in the correct position. Remove the fixation clip for the heat exchanger unit which shall be removed.



4 For removing the left heat exchanger (view from front) carefully remove the temperature sensor from the heat exchanger unit.



5 Lift up and remove the heat exchanger unit and the small foam part in the corner of the module.



Installing the Heat Exchanger Assemblies

Installing the Heat Exchanger Assemblies (G1316A/G1316B SL)

When If the heat exchanger is leaking, blocked or does not heat/cool or other assemblies have to be removed

Tools required Screwdriver Pozidriv 1 PT3
Wrench 1/4 – 5/16 inch for capillary connections

Parts required	#	Part number	Description
	1	G1316-60007	Heat exchanger assembly (left), includes ambient temperature sensor
	1	G1316-60006	Heat exchanger assembly (right)

Preparations The heat exchanger(s) are removed as described in “[Removing the Heat Exchanger Assemblies \(G1316A/G1316B SL\)](#)” on page 140.

CAUTION

The flexible cables close to the heat exchanger assemblies may be easily damaged.

→ Be careful that the flexible cables close to the heat exchanger assemblies are not damaged, especially during steps 3 through 6.

CAUTION

The ambient temperature sensor may get damaged if not installed correctly.

→ Ensure that the ambient temperature sensor is completely plugged into the rear of the top plastic panel.

CAUTION


New foam parts have been introduced for enhanced performance of the G1316C SL Plus.

→ However, using these foam parts for G1316A or G1316B SL may change thermal properties of these modules and bias measurement results.


9 Repair

Installing the Heat Exchanger Assemblies


- 1** Replace the leak tubing assembly into its location on leak base. Ensure that it keeps in this position during the next steps.




- 2** Replace the heat exchanger assembly. A screwdriver might be helpful to insert the silicon isolation.



- 3** Carefully insert the top plastic panel together with the Z-panel into the guide and press it half-way down.




- 4** Carefully plug the temperature sensor into the rear of the top plastic panel.




Installing the Heat Exchanger Assemblies


5 Press the Z-panel together with the top plastic panel completely down.




6 Press down completely until it clicks into its holding position.



7 Fix the Z-panel with the two screws.




8 Reconnect the heat exchanger cables to the processor board and the grounding connection of the column switching valve.



9 Repair

Installing the Heat Exchanger Assemblies

9 Carefully replace the heat exchanger cables into the foam channels.



Next Steps:

- 10** Reinstall the foam section, the top cover and front cover, see "Installing the Foam and the Top Cover (G1316A/G1316B SL)" on page 162.
- 11** Replace the column compartment into stack.
- 12** Reconnect capillaries.
- 13** Reconnect the power cable.
- 14** Turn on the column compartment.

Installing the Heat Exchanger Assembly (G1316C SL Plus)

When If the heater is leaking, blocked or does not heat/cool or other assemblies have to be removed.

Tools required Screwdriver Pozidriv 1 PT3
Wrench 1/4 – 5/16 inch for capillary connections

Parts required	#	Part number	Description
	1	G1316-60007	Heat exchanger assembly (left), includes ambient temperature sensor
	1	G1316-60006	Heat exchanger assembly (right)
	1	G1316-68712	EPP Foam Part Kit

Preparations

- Turn OFF the column compartment.
- Disconnect the power cable.
- Disconnect capillaries.
- Remove column compartment from stack and place it on the working bench.
- Remove the front cover, top cover and top foam section (“[Removing the Top Cover and Foam](#)” on page 110).

CAUTION

The flexible cables close to the heat exchanger assemblies may be easily damaged.

→ Be careful that the flexible cables close to the heat exchanger assemblies are not damaged, especially during steps 3 through 6.

CAUTION

The ambient temperature sensor may get damaged if not installed correctly.

→ Ensure that the ambient temperature sensor is completely plugged into the rear of the top plastic panel.

CAUTION

Bias measurement results.

Foam parts have been introduced for improving the thermostat performance.


→ Not using these parts for G1316C SL Plus can reduce thermostat performance and bias measurement results.

9 Repair


Installing the Heat Exchanger Assemblies

- 1** Insert the heat exchanger unit and the small foam part in the corner of the module. This foam part is part of the Foam Part Kit **G1316-68712**.


Small foam part




- 2** For the left heat exchanger carefully reinstall the temperature sensor from the heat exchanger unit.




- 3** On both sides of the valve actuator, fixation clips shall keep the flexible boards of the heat exchanger assemblies in the correct position. Install the fixation clip for the heat exchanger unit which has been installed.



- 4** Connect the 4 heat exchanger cables from the processor board, which are 2 flexible board cables for the column tag reader and heat sensor and 2 power cables (each pair red/black) located below these cables.



5 Install the Z-Panel by closing 3 screws



Exchanging the Power Supply

Repair of the power supply assembly always involves exchange of the complete assembly. It has no serviceable parts inside.

When If defective

Tools required Screwdriver Pozidriv 1 PT3
Wrench 1/4 inch
Wrench 5 mm and 7 mm


Parts required	#	Part number	Description
	1	0950-2528	Power supply

Preparations Turn OFF the column compartment.
Disconnect the power cable.
Disconnect capillaries.
Remove column compartment from stack and place it on the working bench.
Remove the front cover, top cover and top foam section, see [“Removing the Top Cover and Foam”](#) on page 110.
Remove the column switching valve (if installed), see [“Removing a Valve from the Thermostatted Column Compartment \(G1316A/G1316B SL\)”](#) on page 114 or [“Removing the sliding unit \(G1316C SL Plus\)”](#) on page 117.
Remove the processor board, see [“Exchanging the Main Board \(G1316A/G1316B SL\)”](#) on page 124.
Remove the fan assemblies, see [“Exchanging the Fan”](#) on page 138.
Remove the heat exchanger assemblies, see [“Removing the Heat Exchanger Assemblies \(G1316A/G1316B SL\)”](#) on page 140.


NOTE

The leak tubing assembly might fall out of its position.


1 Remove the leak sensor cable out of the foam channel. Carefully remove the bottom foam.




2 Unscrew the power supply at the rear of the column compartment.



3 Press down the power switch light pipe to remove it from the coupler.



4 Remove the power supply completely. Re-use the coupler on the new power supply.




9 Repair

Exchanging the Power Supply

NOTE


The power supply can be replaced entirely if damaged. Do not disassemble the power supply, it does not contain serviceable parts.

- 5** Insert the power supply into its location and fix it with the screw at the rear panel.




- 6** Press down and clip in the power switch light pipe into the power supply.

Power switch
light pipe



- 7** Reinstall bottom foam part.



Next Steps:

- 8** Reinstall the processor board, see [“Exchanging the Main Board \(G1316A/G1316B SL\)”](#) on page 124.
- 9** Reinstall the fan assemblies, see [“Exchanging the Fan”](#) on page 138.
- 10** Reinstall the heat exchanger assemblies, see [“Installing the Heat Exchanger Assemblies \(G1316A/G1316B SL\)”](#) on page 145.
- 11** Replace the foam section, the top cover and front cover, see [“Installing the Foam and the Top Cover \(G1316A/G1316B SL\)”](#) on page 162.
- 12** Replace column compartment into the stack.
- 13** Reconnect the power cable.
- 14** Turn on the column compartment.

9 Repair

Replacing the Leak Sensor or Leak Base (G1316A/G1316B SL)

Replacing the Leak Sensor or Leak Base (G1316A/G1316B SL)

When If leak sensor is defective or leak base is damaged

Tools required

- Screwdriver Pozidriv 1 PT3
- Screwdriver flat blade
- Wrench 1/4 inch
- Hexagonal wrench 3 mm


Parts required	#	Part number	Description
	1	5061-3356	Leak sensor assembly
	1	G1316-43101	Leak base (part of leak panel kit G1316-68700)

Preparations

- Turn OFF the column compartment.
- Disconnect the power cable.
- Disconnect capillaries.
- Remove column compartment from stack and place it on the working bench.
- Remove the front cover, top cover and top foam section, see [“Removing the Top Cover and Foam”](#) on page 110.

Replacing the Leak Sensor or Leak Base (G1316A/G1316B SL)


1 Disconnect the leak sensor assembly from the processor board and pull the cable out of the foam channel.




2 Remove the column switching valve (if installed), see "Removing a Valve from the Thermostatted Column Compartment (G1316A/G1316B SL)" on page 114 or "Removing the sliding unit (G1316C SL Plus)" on page 117.

3 Remove the heat exchanger assemblies, see "Removing the Heat Exchanger Assemblies (G1316A/G1316B SL)" on page 140.

4 Locate the clips.




5 Remove the clips (shown from the inside of the column compartment) on both sides using a flat screwdriver.




9 Repair

Replacing the Leak Sensor or Leak Base (G1316A/G1316B SL)


- 6** Remove the leak base from the cabinet by unlocking it with a flat blade on the right and left side of the leak base.




- 7** Remove the leak sensor assembly from the rear of the leak base.



- 8** Replace the leak sensor assembly into the leak base.




- 9** Route the leak sensor cable through the z-panel into the left foam channel.




Replacing the Leak Sensor or Leak Base (G1316A/G1316B SL)


10 Replace the leak base into the cabinet until it clicks into the cabinet. Insert the right side first.




11 Position the leak sensor so that it does not touch the bottom of the leak base.



12 Replace the clips (shown from the inside of the column compartment) on both sides using a flat screwdriver.




13 Place the leak tubing assembly back into its location on leak base. Ensure that it keeps in this position during the next steps.




9 Repair

Replacing the Leak Sensor or Leak Base (G1316A/G1316B SL)

14 Reinstall the heat exchanger assemblies, see “[Installing the Heat Exchanger Assemblies \(G1316A/G1316B SL\)](#)” on page 145.



15 Reconnect the leak sensor and heat exchanger cables to the processor board and place the cables in the foam channel.



Next Steps:

16 Reinstall the foam section, the top cover and front cover, see “[Installing the Foam and the Top Cover \(G1316A/G1316B SL\)](#)” on page 162.

17 Place the column compartment back into the stack.

18 Reconnect the cables.

19 Turn on the column compartment.

Replacing Status Light Pipe

When When part is broken


Tools required Screwdriver Pozidriv 1 PT3

Parts required	#	Part number	Description
	1	5041-8384	Status light pipe

Preparations

- Turn OFF the column compartment.
- Disconnect the power cable.
- Disconnect capillaries.
- Remove column compartment from stack and place it on the working bench.
- Remove the front cover, top cover and top foam section, see [“Removing the Top Cover and Foam”](#) on page 110.

1 The status light pipe is clipped into the top cover.



Next Steps:

- 2** Reinstall the foam section, the top cover and front cover, see [“Installing the Foam and the Top Cover \(G1316A/G1316B SL\)”](#) on page 162.
- 3** Place the column compartment back into the stack.
- 4** Reconnect the cables.
- 5** Reconnect the capillaries.
- 6** Turn on the column compartment.

Installing the Foam and the Top Cover


Installing the Foam and the Top Cover (G1316A/G1316B SL)

When After all repairs have been completed


Tools required Screwdriver Pozidriv 1 PT3

Preparations The column compartment is open and other procedures have been carried out


1 Route the valve connector through the top foam and carefully fit the top foam into the column compartment.




2 Reconnect the valve connector to the main board.



3 Make sure that the foam is installed correctly and is located in the safety light switch.




4 Position of the foam in the safety light switch.




5 Place the top plate on the foam and slide it towards the rear and fix the screws at the rear of the top plate.

Ensure correct fit with Z-plane




6 Place the top cover into the guides.




9 Repair

Installing the Foam and the Top Cover

7 Reinstall the cover.



8 Close the front panel.



Next Steps:

- 9** Place the column compartment back into the stack.
- 10** Reconnect the cables.
- 11** Turn on the column compartment.

Installing the Top Cover and Foam (G1316C SL Plus)

When After repairs of internal parts have been completed

Tools required Screwdriver Pozidriv 1 PT3

Preparations The column compartment is open and other procedures have been completed

CAUTION


Blocked valve

Not bringing the valve head to the outer position will cause the valve to stay permanently in the inner position due to a blockage of the cables.

→ Move the valve head to the outer position.

1 If a valve actuator unit is installed, route the cables of the valve tag reader, valve actuator encoder reader and valve actuator drive control through the large central hole of the top foam part.

2 Move the valve head to the outer position.




9 Repair

Installing the Foam and the Top Cover

- 3** Route cables through the top foam part and connect them to the main board.

Valve actuator encoder reader


Door sensor




Valve tag reader

Valve actuator drive control

- 4** Make sure that the foam is installed correctly and is located in the safety light switch.




- 5** Position of the foam in the safety light switch.




- 6** Place the top plate on the foam and slide it towards the rear and fix the screws at the rear of the top plate.

Ensure correct fit with Z-plane




Installing the Foam and the Top Cover


7 Place the top cover into the guides.



8 Reinstall the cover.



9 Close the front panel.



Next Steps:

- 10** Place the column compartment back into the stack.
- 11** Reconnect the cables.
- 12** Turn on the column compartment.

9 Repair

Assembling the Main Cover

Assembling the Main Cover

When If cover was broken

Tools required None

Parts required	#	Part number	Description
	1	G1316-68713	Plastics kit (includes base, top, left and right)

NOTE

The plastics kit contains all parts, but it is not assembled.


CAUTION

Wrong assembled


In case you insert the left or right side in the opposite position, you may not be able to remove the side from the top part.

→ Take care not to mix up left and right side.

1 Place the top part on the bench and insert the left and right side into the top part.



2 Replace the cover.



9 Repair

Installing the Radio Frequency Shield (G1316C SL Plus)


Installing the Radio Frequency Shield (G1316C SL Plus)

When If the Thermostatted Column Compartment SL Plus shall be operated without valve and sliding unit, the radio frequency shield is mandatory.


Parts required	#	Part number	Description
	1	G1316-67002	Valve Cover Kit

- Preparations**
- Turn OFF the column compartment.
 - Disconnect the power cable.
 - Disconnect capillaries.
 - Remove column compartment from stack and place it on the working bench.
 - Remove the front cover, top cover and top foam section (“[Removing the Top Cover and Foam](#)” on page 110).

1 Remove the valve liner.




2 Replace the valve liner by a valve cover **G1316-44123**, which fits to the same position and clip it in at its top.



Installing the Radio Frequency Shield (G1316C SL Plus)

- 3** Insert the radio frequency shield between the Z-panel and valve cover.



9 Repair

Installing the leak sensor (G1316C SL Plus)

Installing the leak sensor (G1316C SL Plus)

This section describes how to install the leak sensor for the Thermostatted Column Compartment SL Plus (G1316C SL Plus). New modules of the G1316A and G1316B SL versions use the same design. For existing G1316A and G1316B SL modules, please refer to [“Replacing the Leak Sensor or Leak Base \(G1316A/G1316B SL\)”](#) on page 156.

When If leak sensor is defective or leak base is damaged

Tools required

- Screwdriver Pozidriv 1 PT3
- Screwdriver flat blade
- Wrench 1/4 inch
- Hexagonal wrench 3 mm

Parts required


#	Part number	Description
1	5061-3356	Leak sensor assembly
1	G1316-43101	Leak base (part of leak panel kit G1316-68700)

Preparations

- Turn OFF the column compartment.
- Disconnect the power cable.
- Disconnect capillaries.
- Remove column compartment from stack and place it on the working bench.
- Remove the front cover, top cover and top foam section, see [“Removing the Top Cover and Foam”](#) on page 110.
- Remove the sliding unit, see [“Removing the sliding unit \(G1316C SL Plus\)”](#) on page 117


Installing the leak sensor (G1316C SL Plus)

- 1** Insert the leak sensor to the hole below the valve liner (rear view).



Leak sensor


- 2** Insert the leak sensor to the hole below the valve liner (front view).



Leak sensor

- 3** Route the leak sensor cable below the overhang and through the channel in the bottom foam part. Connect the leak sensor to the main board.

Leak sensor cable



To be routed below bottom foam part here

9 Repair

Replacing the Door Sensor (G1316C SL Plus)

Replacing the Door Sensor (G1316C SL Plus)

When If the door sensor is defective.

Tools required


- Screwdriver Pozidriv 1 PT3
- Screwdriver flat blade
- Wrench 1/4 inch
- Hexagonal wrench 3 mm

Parts required	#	Part number	Description
	1	G1316-81603	Door Sensor


Preparations

- Turn OFF the column compartment
- Disconnect the power cable
- Disconnect capillaries
- Remove column compartment from stack and place it on the working bench


1 Remove the Z-Panel and upper leak panel by opening 3 screws.



2 Remove the RF shield by carefully pulling down (1) the clips.




3 Pull the door sensor out of the leak panel.

**NOTE**

For installing a new door sensor, route the sensor cable through the leak panel as shown in figure above (step 2), clip in the RF shield and fix the panel to the module frame.

9 Repair

Replacing the Door Sensor (G1316C SL Plus)



10 Parts and Materials for Maintenance

Valve Options Overview	178
Heater and Cooling Devices for G1316B SL/G1316C SL Plus	179
Column Switching Valve 2 Position/6 Port (G1316A/G1316B SL)	181
Column Switching Valve 8 Position/9 Port (G1316C SL Plus)	183
Micro Column Switching Valve 2 Position/6 Port (G1316A/G1316B SL)	185
Micro Column Switching Valve 2 Position/10 Port (G1316A/G1316B SL)	186
Accessory Kits	188
G1316A Accessory Kit (Standard)	188
G1316A Accessory Kit (2PS/10PT modules)	189
G1316B SL/G1316C SL Plus Accessory Kit (Standard)	189
G1316B SL/G1316C SL Plus Capillary System Kit	190
G1316B SL Micro Valve Kit 2 Position/10 Port	192
Column Regeneration Kit (G1316A/G1316B SL)	193
Accessories (G1316C SL Plus)	194
Plastic Parts	195
Leak Parts	196

This chapter provides information on parts for maintenance.



Valve Options Overview

This overview gives a summary of the main parts and assemblies. More details are available with each valve option in this chapter.

Table 10 Valves for G1316A and G1316B SL

Module	Valve Description	Valve	Rotor Seal	Stator
G1316A (#055) G1316-68700	"Column Switching Valve 2 Position/6 Port (G1316A/G1316B SL)" on page 181	0101-0920 ¹	0100-1855 (Vespel) 0100-1854 (Tefzel) 0100-2233 (PEEK)	0100-1851 (Face) 0100-1850 (Head) 0100-1852 (Seal)
G1316A (#056)	"Micro Column Switching Valve 2 Position/6 Port (G1316A/G1316B SL)" on page 185	0101-1051	0100-2087 (Vespel)	0101-2089
G1316A (#057) G1316-68709	"Micro Column Switching Valve 2 Position/10 Port (G1316A/G1316B SL)" on page 186	0101-1343 ²	0101-1360	0101-1362
G1316B (#055)	"Column Switching Valve 2 Position/6 Port (G1316A/G1316B SL)" on page 181 (600 bar)	0101-1420	0101-1409	0101-1417
G1316B (#057)	"Micro Column Switching Valve 2 Position/10 Port (G1316A/G1316B SL)" on page 186 (600 bar)	0101-1419	0101-1415	0101-1421

¹ re-build kit 0101-1258 includes 3-groove rotor seal, stator face assy, isolation seal, instructions.

² re-build kit 0101-1360 includes PEEK rotor seal, PEEK stator face, hex key.

Table 11 Valves for G1316C SL Plus





Kit	Kit Description	Valve Head	Rotor Seal	Stator
G4230A	Method Development Valve Kit, low pressure, includes 8pos/9port valve	5067-4108	5067-4113 ¹	5067-4112
G4230B	Method Development Valve Kit, high pressure, includes 8pos/9port valve	5067-4107	5067-4111	5067-4110

¹ kit with stator face and rotor seal

Heater and Cooling Devices for G1316B SL/G1316C SL Plus

The use of these heater and cooling devices is described in Technical Notes or in the Agilent 1200 Series Rapid Resolution LC System (1200 RRLC System) manual.

Table 12 Heater and Cooling Devices for G1316B SL/G1316C SL Plus

Item	Description	Part Number
	Heater long-up (0.12 mm i.d., 1.6 µl internal volume) (G1316B SL/G1316C SL Plus) Part of “G1316B SL/G1316C SL Plus Capillary System Kit” on page 190.	G1316-80002
	Heater long-down (0.12 mm i.d., 1.6 µl internal volume) (G1316B SL/G1316C SL Plus) Part of “G1316B SL/G1316C SL Plus Capillary System Kit” on page 190.	G1316-80003
	Post-column cooler, (0.12 mm i.d., 1.5 µl internal volume) (G1316B SL/G1316C SL Plus) Part of “G1316B SL/G1316C SL Plus Capillary System Kit” on page 190.	G1316-80004
	Carrier for Heater and Cooler (G1316B SL), includes 3 screws SKT-HD-CAP, M3 x 0.5, 12 mm long Part of “G1316B SL/G1316C SL Plus Capillary System Kit” on page 190.	G1316-83200 0515-1052

10 Parts and Materials for Maintenance

Heater and Cooling Devices for G1316B SL/G1316C SL Plus

Table 13 Consumables (G1316C SL Plus)

Description	Part Number
Column Clip Set, 8 Colors	5042-9918
Carrier for Heat Exchanger G1316C SL Plus	G1316-89200
Fitting Holder Assy, includes following items:	G1316-68706
<ul style="list-style-type: none"> • Fitting Fork • Fitting Clip • Screws (Pack of 4) 	




Figure 30 Heater and Cooling Devices for G1316B SL

Column Switching Valve 2 Position/6 Port (G1316A/G1316B SL)

Table 14 Column Switching Valve 2PS/6PT for G1316A/G1316B SL

Item	Description	Part Number
	Column switching valve kit, includes all parts required for installation	G1353-68700
	Column switching valve (complete assembly)	0101-0920
	Cover plate (when switching valve is not installed)	G1316-44103
	Capillary Kit Column Switching includes two capillaries (0.17mm i.d., 180 mm) and three capillaries (0.17 mm i.d., 90 mm)	G1316-68708 G1313-87305 G1316-87300
	Rhebuild kit for 7750-030 valve, includes: 3-groove rotor seal, stator face assy, isolation seal, instructions	0101-1258
1	Stator screws	1535-4857
2	Stator Head	0100-1850
3	Stator face	0100-1851
4	Stator ring	
5	Rotor seal 3 grooves (Tefzel)	0100-1854
	Rotor seal 3 grooves (VespeI)	0100-1855
	Rotor seal 3 grooves (PEEK)	0100-2233
6	Isolation seal	0100-1852

10 Parts and Materials for Maintenance

Column Switching Valve 2 Position/6 Port (G1316A/G1316B SL)




Figure 31 Column Switching Valve Parts

Column Switching Valve 8 Position/9 Port (G1316C SL Plus)

Column Switching Valve Parts High Pressure (G1316C SL Plus)

Table 15 Valve 8 Position/9 Port, High Pressure (G1316C SL Plus)

Item	Description	Part Number
	Valve Head, 8 Position/9 Port, High Pressure	5067-4107
1	Stator Screws	1535-4857
2	Stator Head	5067-4110
3	Rotor Seal High Pressure	5067-4111
4	Isolation Seal	0100-1852




Figure 32 Column Switching Valve Parts (5067-4107)

10 Parts and Materials for Maintenance

Column Switching Valve 8 Position/9 Port (G1316C SL Plus)

Column Switching Valve Parts 400 bar (G1316C SL Plus)

Table 16 Valve 8 Position/9 Port, 400 bar (G1316C SL Plus)

Item	Description	Part Number
	Valve Head, 8 Position/9 Port, 400 bar	5067-4108
1	Stator Screws	1535-4857
2	Stator Head	5067-4112
3, 4	Stator Face/Rotor Seal 400 bar	5067-4113
5	Isolation Seal	0100-1852




Figure 33 Column Switching Valve Parts (5067-4108)

Micro Column Switching Valve 2 Position/6 Port (G1316A/G1316B SL)

Table 17 Micro Column Switching Valve 2PS/6PT for G1316A/G1316B SL, 400 bar

Item	Description	Part Number
	Micro Column Switching Valve 2PS/6PT, 400 bar	0101-1051
	Stator face	0100-2089
	Rotor seal 3 grooves	0100-2087

Table 18 Micro Column Switching Valve 2PS/6PT for G1316B SL, 600 bar

Item	Description	Part Number
	Micro Column Switching Valve 2PS/6PT, 600 bar	0101-1420
	Stator, 600 bar	0101-1417
	Rotor seal 3 grooves, 600 bar	0101-1409

10 Parts and Materials for Maintenance

Micro Column Switching Valve 2 Position/10 Port (G1316A/G1316B SL)

Micro Column Switching Valve 2 Position/10 Port (G1316A/G1316B SL)

NOTE

Technical details can be found in the Technical Note that is supplied with the kit.

Table 19 Micro Column Switching Valve 2PS/10PT for G1316A/G1316B SL, 400 bar

Item	Description	Part Number
	2PS/10 PT Valve kit, includes all parts required for installation	G1316-68709
	Rebuild kit, includes PEEK rotor seal, PEEK stator face, hex key	0101-1360
	2PS/10 PT valve	0101-1343
	Rotor seal (Vespel)	0101-1361
	Stator face	0101-1362
	Capillary kit, see Table 21 on page 186	G1316-68711

Table 20 Micro Column Switching Valve 2PS/10PT 600 bar for G1316B SL, 600 bar

Item	Description	Part Number
	Column Switching Valve 2PS/10PT for μ -LC System, 600 bar	0101-1419
	Stator, 600 bar	0101-1421
	Rotor seal 5 grooves, 600 bar	0101-1415

Table 21 Capillary Kit (G1316-68711)

From	To	ID [mm]	Length [mm]	Qty	Part number	Remark
Capillaries						
ALS ¹	Valve (port 2)	0.17	700	1	5065-9932	

Micro Column Switching Valve 2 Position/10 Port (G1316A/G1316B SL)

Table 21 Capillary Kit (G1316-68711)

From	To	ID [mm]	Length [mm]	Qty	Part number	Remark
Valve (port 3)	TCC 3 µl (In)	0.17	105	1	5021-1816	
TCC ² 3 µl (Out)	Column 1	0.17	105	1	5021-1816	
Column 1	Valve (port 6)	0.17	105	1	5021-1816	for long column
Column 1	Valve (port 6)	0.17	200	1	5065-9931	for short column
Valve (port 7)	Detector (In)	0.17	280	1	5021-1818	
Valve (port 1)	TCC 6 µl (In)	0.17	105	1	5021-1816	
TCC ^{**} 6 µl (Out)	Column 2	0.17	105	1	5021-1816	
Column 2	Valve (port 8)	0.17	105	1	5021-1816	for long column
Column 2	Valve (port 8)	0.17	200	1	5065-9931	for short column
Valve (port 5)	Valve (port 10)	0.17	105	1	5021-1816	
Regeneration pump	Valve (port 4)	0.25	800	1	5065-9930	
Valve (port 9)	Waste	0.6	2000		5062-2463	PTFE
Ferrules, screws, fingertight fittings, etc.						
1/16" fittings and ferrules				2	5062-2418	10/pk
fingertight fitting long				1	5062-8541	10/pk
fitting screw long				10	5065-4454	10/pk
fitting screw extra long				10	5065-9967	10/pk
front ferrule				1	5180-4108	10/pk
back ferrule				1	5180-4114	10/pk
Peek tubing 1/16"		0.18	1500	1	0890-1763	
Plastic tubing cutter				1	8710-1930	
Hex key 3/32"				1	8710-2462	
Rheotool Socket wrench 2 x 1/4"				1	8710-2391	

¹ ALS - Autosampler² TCC - Thermostatted Column Compartment (heat exchanger: 3 µl left or 6 µl right)

Accessory Kits

The accessory kits (for G1316A, G1316B SL or G1316C SL Plus) contain accessories and tools needed for the installation and maintenance.

G1316A Accessory Kit (Standard)

Table 22 G1316A Accessory Kit (Standard)

Item	Description	Part Number
	G1316A Accessory Kit (Standard)	G1316-68705
	Column identification tag (blank) for re-ordering use (pack of 3)	5062-8588
	Column clip, for re-order use (pack of 6)	5063-6526
	Corrugated tubing (to waste), re-order 5 m	5062-2463
	CAN cable 0.5 m	5181-1516
	Wrench open end 1/4 – 5/16 inch	8710-0510
	Wrench open end, 5/16 – 3/8 inch	8710-2409
	Capillary column-heat exchanger 90 mm lg, 0.17 i.d. (not assembled) contains items 2, 3 and 4	G1316-87300
	Ferrule front SST (pack of 2)	1
	Ferrule back SST (pack of 2)	*
	Fitting SST (pack of 2)	*

¹ re-order 5062-2418, pack of 10 each of fittings, front- and back ferrule

G1316A Accessory Kit (2PS/10PT modules)

Table 23 G1316A Accessory Kit (2PS/10PT modules)

Item	Description	Part Number
	G1316A Accessory Kit 2PS/10PT	G1316-68725
	Column identification tag (blank) for re-ordering use (pack of 3)	5062-8588
	Column clip, for re-order use (pack of 6)	5063-6526
	Corrugated tubing (to waste), re-order 5 m	5062-2463
	CAN cable 0.5 m	5181-1516
	Wrench open end 1/4 – 5/16 inch	8710-0510
	Wrench open end, 5/16 – 3/8 inch	8710-2409
	PEEK Capillary 280 mm lg, 50 μ i.d. (pack of 4)	G1316-87309
	MIC Valve Fitting (pack of 2)	5022-2186
	Column holder for μ -LC columns (pack of 2)	5001-3702

G1316B SL/G1316C SL Plus Accessory Kit (Standard)

Table 24 Accessory Kit (Standard) G1316B SL and G1316C SL Plus

Item	Description	Part Number
	G1316B SL/G1316C SL Plus Accessory Kit (Standard)	G1316-68735
	Column identification tag (blank) for re-ordering use (pack of 3)	5062-8588
	Column clip, qty=2, for re-order use (pack of 6)	5063-6526
	Corrugated tubing (to waste), re-order 5 m	5062-2463
	CAN cable 0.5 m	5181-1516
	Wrench open end 1/4 – 5/16 inch	8710-0510
	Wrench open end, 5/16 – 3/8 inch	8710-2409

10 Parts and Materials for Maintenance

Accessory Kits

Table 24 Accessory Kit (Standard) G1316B SL and G1316C SL Plus

Item	Description	Part Number
	Screwdriver Torx TX8	8710-2509
	Screwdriver Hexagonal 2.5 mm	5965-0028
	Capillary column-heat exchanger 90 mm lg, 0.17 i.d. (not assembled) contains items 2, 3 and 4	G1316-87300
	Capillary column-heat exchanger 115 mm lg, 0.17 i.d. (not assembled) contains items 2, 3 and 4	G1316-87321
	Capillary column-heat exchanger 170 mm lg, 0.17 i.d. (not assembled) contains items 2, 3 and 4	G1316-87323
	Ferrule front SST (pack of 2)	1
	Ferrule back SST (pack of 2)	*
	Fitting SST (pack of 2)	*

¹ re-order 5062-2418, pack of 10 each of fittings, front- and back ferrule

G1316B SL/G1316C SL Plus Capillary System Kit

G1316B SL/G1316C SL Plus Capillary System Kit

Table 25 G1316B SL Capillary System Kit G1316-68744 (G1316B#060)

Item	Description	Part Number
*	2 Carriers for Heater or Cooling Devices	G1316-83200
*	Heater long-up (0.12 mm i.d., 1.6 µl internal volume)	G1316-80002
*	Heater long-down (0.12 mm i.d., 1.6 µl internal volume)	G1316-80003
*	Post-column cooler (0.12 mm i.d., 1.5 µl internal volume)	G1316-80004
	Capillary System Kit, see Table 26 on page 191 for details	G1316-68716

For items * see also “[Heater and Cooling Devices for G1316B SL/G1316C SL Plus](#)” on page 179.

Table 26 Capillary System Kit G1316-68716

Item	Description	Part Number
	Seat Capillary 100 mm x 0.12 mm, 0.8 OD	G1367-87303
	DAD Heat Exchanger Capillary 310 mm x 0.12 mm	G1315-87339
	SST Capillary 340 mm x 0.12 mm, m/m	G1316-87319
	SST Capillary 300 mm x 0.12 mm, m/m	G1316-87318
	SST Capillary 210 mm x 0.12 mm, m/m	G1316-87317
	SST Capillary 170 mm x 0.12 mm, m/m	G1316-87316
	SST Capillary 130 mm x 0.12 mm, m/f	G1316-87315
	SST Capillary 90 mm x 0.12 mm, m/f	G1316-87314
	SST Capillary 70 mm x 0.12 mm, m/f	G1316-87313
	SST Capillary 50 mm x 0.12 mm, m/f	G1316-87312
	SST Capillary 170 mm x 0.12 mm, m/f	G1316-87327
	SST Capillary 500 mm x 0.12 mm, m/m	G1316-87309
	SST Capillary 500 mm x 0.12 mm, m/m	G1315-87307

G1316C SL Plus Capillary System Kits

Table 27 G1316C Capillary System Kits

Description ¹	Part Number
Solvent selection tubing kit, 4 solvents	5067-4601
Method Development Capillary Kit, low dispersion, short column	5067-1595
Method Development Capillary Kit, low dispersion, long column	5067-1596
Method Development Capillary Kit, general purpose	5067-1597
RRHT Selectivity Method Development Kit, 2.1 mm ID	5190-1431
RRHT pH Method Development Kit, 2.1 mm ID	5190-1432
RRHT Selectivity Method Development Kit, 4.6 mm ID	5190-1433
RRHT pH Method Development Kit, 4.6 mm ID	5190-1434

Table 27 G1316C Capillary System Kits

Description ¹	Part Number
Rapid Resolution Selectivity Method Development Kit	5190-1435
Rapid Resolution pH Method Development Kit	5190-1436

¹ for capillary kit contents, please refer to the Method Development Solution User and Installation Guide (**G4230-90000**)

G1316B SL Micro Valve Kit 2 Position/10 Port

Table 28 G1316B SL Micro Valve Kit 2PS/10PT

Item	Description	Part Number
	G1316B SL Micro Valve Kit 2PS/10PT	G1316-68745
	Column identification tag (blank) for re-ordering use (pack of 3)	5062-8588
	Column clip, for re-order use (is pack of 6)	5063-6526
	Corrugated tubing (to waste), re-order 5 m	5062-2463
	Wrench open end 1/4 – 5/16 inch	8710-0510
	Wrench open end, 5/16 – 3/8 inch	8710-2409
	Screwdriver Torx TX8	8710-2509
	Screwdriver Hexagonal 2.5 mm	5965-0028
	2 Column holders for μ -LC columns	5001-3702
	Column Regeneration Kit for μ -LC columns, see Table 29 on page 193	G1316-68721
	Capillary column-heat exchanger 90 mm lg, 0.17 i.d. (not assembled) contains items 2, 3 and 4	G1316-87300
	Capillary column-heat exchanger 115 mm lg, 0.17 i.d. (not assembled) contains items 2, 3 and 4	G1316-87321
	Capillary column-heat exchanger 170 mm lg, 0.17 i.d. (not assembled) contains items 2, 3 and 4	G1316-87323

Column Regeneration Kit (G1316A/G1316B SL)

Refer to [Figure 34](#) on page 194 for connection diagram.

Table 29 Column Regeneration Kit

Description	where used	Part Number
Column Regeneration Kit		G1316-68721
SST Capillary, 700 mm x 0.17 mm, 1/32 - 1/32	column to cell	G1312-87304
SST Capillary, 100 mm x 0.12 mm, 1/32 - 1/32	switching capillary	G1316-27301
SST Capillary, 100 mm x 0.12 mm, male/female 1/32 - 1/16	adapter capillary	G1316-87304
SST Capillary, 340 mm x 0.12 mm, male/female 1/32 - 1/16	WPS to valve	G1316-87305
SST Capillary, 70 mm x 0.12 mm, male/female 1/32 - 1/16 (pack of 2)	valve to heatexchanger	G1316-87306
SST Capillary 50 mm x 0.12 mm, male/female	column to cell	G1316-87312
SST Capillary 70 mm x 0.12 mm, male/female	column to cell	G1316-87313
SST Capillary, 75 mm x 0.12 mm, male/female 1/32 - 1/16	valve to detector	G1316-87326
Seat Capillary, 100 mm x 0.12 mm (pack of 2)		G1367-87303
PEEK fitting, special for Chip-LC		G4240-43200
Flexible PEEK Tubing, 450 mm x 0.4 mm	valve to waste	5022-6503

10 Parts and Materials for Maintenance

Accessory Kits




Figure 34 Connection Diagram for Column Regeneration

Accessories (G1316C SL Plus)

Table 30 Accessories (G1316C SL Plus)

Description	Part Number
Transportation Lock Kit G1316C SL Plus, includes following items:	G1316-67001
• Lock Plate	
• Screw M4	
• Screw M3x8 (pack of 4)	
• Spring Washer	
• Transportation Valve Head	

Plastic Parts

Table 31 Plastic Parts

Item	Description	Part Number
2	Front cover G1316A (1200 Series)	G1316-68714
2	Front cover G1316B SL (1200 Series)	G1316-68724
2	Front cover G1316C SL Plus (1200 Series)	G1316-68754
3	Name plate Agilent (1200 Series)	5042-8901




Figure 35 Plastic Parts

Leak Parts

Table 32 Leak Parts G1316A/G1316B SL

Item	Description	Part Number
1	Leak funnel	5041-8388
2	Leak funnel holder	G1316-42300
3	Waste assembly, includes complete Y-tubing assembly with leak funnel	G1316-60002
	Corrugated waste tube (reorder pack), 5 m	5062-2463




Figure 36 Leak Parts

Table 33 Leak Parts G1316C SL Plus

Item	Description	Part Number
	Leak Panel Kit, includes following items: • Leak Panel Top • Leak Panel Base	G1316-68722
	Leak Tube Kit, includes following items: • Funnel Holder G1316C SL Plus • Tubing-flex polyethylene • Leak Funnel	G1316-67000
1	Capillary Guide	G1316-42303




Figure 37 Capillary Guide

10 Parts and Materials for Maintenance

Leak Parts



11 Parts for Repairs

Overview of Main Assemblies	200
Sheet Metal Kit	203
Plastic Parts	205
Foam Parts	207
Power and Status Light Pipes	209
Leak Parts	210
Internal Valve Drive Parts (G1316C SL Plus)	212

This chapter provides information on parts for repair.



Overview of Main Assemblies




Figure 38 Main Assemblies

Table 34 Overview of Main Assemblies

Item	Description	Part Number
1	Column compartment main board CCM for G1316A, requires minimum firmware A.05.05 (exchange part)	G1316-66530
		G1316-69530
1	Column compartment main board CCM for G1316B SL, requires minimum firmware A.06.02 (exchange part)	G1316-66540
		G1316-69540
1	Column compartment main board CCM for G1316C SL Plus, requires minimum firmware A.06.10	G1316-61050
	Hexagonal nut for GPIB connector	0380-0643
	Hexagonal nut for RS-232 connector	1251-7788
	Cable CAN to Agilent 1200 Series modules 0.5 m	5181-1516
	Cable CAN to Agilent 1200 Series modules 1 m	5181-1519
3	Power supply assembly, additional power and status light parts, see “The Main Power Supply Assembly” on page 244	0950-2528
4	Fan assembly	3160-1017
5	Heatexchanger (left), 3 µl for G1316A	G1316-60007
5	High Temp Heatexchanger (left), 3 µl for G1316B	G1316-60017
6	Heatexchanger (right) , 6 µl for G1316A	G1316-60006
6	High Temp Heatexchanger (right) , 6 µl for G1316B	G1316-60016
7	Valve (optional), see “Column Switching Valve 2 Position/6 Port (G1316A/G1316B SL)” on page 181, or “Micro Column Switching Valve 2 Postion/6 Port (G1316A/G1316B SL)” on page 185 or “Micro Column Switching Valve 2 Position/10 Port (G1316A/G1316B SL)” on page 186	
8	Leak sensor assembly	5061-3356
9	Leak handling parts	See “Leak Parts” on page 210
	Cover plate (when switching valve is not installed)	G1316-44103
	Front cover and plastic parts (housing)	See “Plastic Parts” on page 205

11 Parts for Repairs

Overview of Main Assemblies

Table 34 Overview of Main Assemblies

Item	Description	Part Number
	Sheet metal parts	See “Sheet Metal Kit” on page 203
	Foam parts	See “Foam Parts” on page 207
	Screw and Washer Kit Rear Panel, includes following items: <ul style="list-style-type: none">• Screw M4• Washer• Hexagonal nut for RS-232 connector	G1316-67004

Sheet Metal Kit

Table 35 Sheet Metal Kit Parts G1316A/G1316B SL

Item	Description	Part Number
	Sheet metal kit includes items 1, 2 and 3	G1316-68701
4	RFI shield	G1316-00600
5	RFI spring side	G1316-09100
6	RFI spring bottom	G1316-09102




Figure 39 Sheet Metal Kit

11 Parts for Repairs

Sheet Metal Kit

Table 36 Sheet Metal Kit (G1316C SL Plus)

Item	Description	Part Number
	Sheet Metal Kit G1316C SL Plus	G1316-68731

Plastic Parts

Table 37 Plastic Parts G1316A/G1316B SL

Item	Description	Part Number
1	Plastic kit, includes base, sides and top (1200 Series)	G1316-68713
2	Front cover G1316A (1200 Series)	G1316-68714
2	Front cover G1316B SL (1200 Series)	G1316-68724
3	Name plate Agilent (1200 Series)	5042-1381

Table 38 Plastic Parts G1316C SL Plus

Item	Description	Part Number
	Front Cover G1316C SL Plus	G1316-68754
	Plastik Cover Kit G1316C SL Plus, includes following items: <ul style="list-style-type: none"> • Top Cover Kit • Left Side Cover G1316C SL Plus • Right Side Cover G1316C SL Plus • Base Cover G1316C SL Plus 	G1316-68723
	Sensor Assy Front Cover	G1316-81603

NOTE

For correct assembling of the top and sides, see [“Assembling the Main Cover”](#) on page 168.

11 Parts for Repairs

Plastic Parts




Figure 40 Plastic Parts

Foam Parts

Table 39 Foam Parts G1316A/G1316B SL

Item	Description	Part Number
1,2	EPP foam kit , includes 1 and 2	G1316-68702
1	Top	
2	Base	

NOTE

Part numbers printed on the foam parts are not orderable.




Figure 41 Foam Parts

11 Parts for Repairs

Foam Parts

Table 40 Foam Parts G1316C SL Plus

Item	Description	Part Number
	EPP Foam Kit G1316A/G1316B SL/G1316C SL Plus	G1316-68712
1	Fixation Clip Kit, 5 clips, includes following items: <ul style="list-style-type: none">• Fixation Clip for Heat Exchanger Flex. Board	G1316-67003




Figure 42 Fixation Clip for Heat Exchanger Flex Board

Power and Status Light Pipes

Table 41 Power and Status Light Pipes

Item	Description	Part Number
	Power supply assembly	0950-2528
1	Power light pipe	5041-8382
2	Status light pipe	5041-8384
3	Power switch button	5041-8381
4	Coupler for power supply actuator	5041-8383




Figure 43 Power and Status Light Pipes

Leak Parts

Table 42 Leak Parts

Item	Description	Part Number
1	Leak sensor	5061-3356
2	O-ring for ambient temperature sensor	0400-0002
3, 4	Leak Kit, includes leak top and leak base (1200 Series) G1316A/G1316B SL	G1316-68720
5	Leak funnel G1316A/G1316B SL	5041-8388
6	Leak funnel holder G1316A/G1316B SL	G1316-42300
7	Waste assembly, includes complete Y-tubing assembly with leak funnel G1316A/G1316B SL	G1316-60002
	Waste tubing 1200 mm long (part of accessory kit)	0890-1711
	Leak Panel Kit, includes following items: • Leak Panel Top • Leak Panel Base	G1316-68722
	Leak Tube Kit, includes following items: • Funnel Holder G1316C SL Plus • Tubing-flex polyethylene • Leak Funnel	G1316-67000




Figure 44 Leak Parts G1316A/G1316B SL


11 Parts for Repairs

Internal Valve Drive Parts (G1316C SL Plus)

Internal Valve Drive Parts (G1316C SL Plus)

Table 43 Internal Valve Drive Parts (G1316C SL Plus)

Item	Description	Part Number
	Actuator Valve	5067-4106
	Sliding Unit G1316C SL Plus	G1316-60000
	Valve Liner	G1316-40501
	Valve Cover Kit, includes following items:	G1316-67002
1	• Valve Cover	
2	• Radio Frequency Shield	





12 Identifying Cables

Cable Overview	214
Analog Cables	216
Remote Cables	219
BCD Cables	224
Auxiliary Cable	226
CAN/LAN Cables	227
External Contact Cable	228
RS-232 Cables	229

This chapter summarizes information on all cables.



Cable Overview


NOTE

Never use cables other than the ones supplied by Agilent Technologies to ensure proper functionality and compliance with safety or EMC regulations.

Type	Description	Part Number
Analog cables	3390/2/3 integrators	01040-60101
	3394/6 integrators	35900-60750
	Agilent 35900A A/D converter	35900-60750
	General purpose (spade lugs)	01046-60105
Remote cables	3390 integrator	01046-60203
	3392/3 integrators	01046-60206
	3394 integrator	01046-60210
	3396A (Series I) integrator	03394-60600
	3396 Series II / 3395A integrator, see details in section "Remote Cables" on page 219	
	3396 Series III / 3395B integrator	03396-61010
	HP 1050 modules / HP 1046A FLD	5061-3378
	HP 1046A FLD	5061-3378
	Agilent 35900A A/D converter	5061-3378
	HP 1040 diode-array detector	01046-60202
	HP 1090 liquid chromatographs	01046-60202
	Signal distribution module	01046-60202
	<i>BCD cables</i>	3396 integrator
General purpose (spade Lugs)		G1351-81600
<i>Auxiliary</i>	Agilent 1100 Series vacuum degasser	G1322-61600

Type	Description	Part Number
<i>CAN cables</i>	Agilent 1100/1200 module to module, 0.5m lg	5181-1516
	Agilent 1100/1200 module to module, 1m lg	5181-1519
<i>External contacts</i>	Agilent 1100/1200 Series interface board to general purpose	G1103-61611
<i>GPIB cable</i>	Agilent 1100/1200 module to ChemStation, 1 m	10833A
	Agilent 1100/1200 module to ChemStation, 2 m	10833B
<i>RS-232 cable</i>	Agilent 1100/1200 module to a computer This kit contains a 9-pin female to 9-pin female Null Modem (printer) cable and one adapter.	34398A
<i>LAN cable</i>	Twisted pair cross over LAN cable, (shielded 3m long) (for point to point connection)	5023-0203
	Twisted pair cross over LAN cable, (shielded 7m long) (for point to point connection)	5023-0202

Analog Cables




One end of these cables provides a BNC connector to be connected to Agilent 1100/1200 Series modules. The other end depends on the instrument to which connection is being made.


Agilent 1100/1200 to 3390/2/3 Integrators

Connector 01040-60101	Pin 3390/2/3	Pin Agilent 1100/1200	Signal Name
	1	Shield	Ground
	2		Not connected
	3	Center	Signal +
	4		Connected to pin 6
	5	Shield	Analog -
	6		Connected to pin 4
	7		Key
	8		Not connected

Agilent 1100/1200 to 3394/6 Integrators

Connector 35900-60750	Pin 3394/6	Pin Agilent 1100/1200	Signal Name
	1		Not connected
	2	Shield	Analog -
	3	Center	Analog +


Agilent 1100/1200 to BNC Connector

Connector 8120-1840	Pin BNC	Pin Agilent 1100/1200	Signal Name
	Shield	Shield	Analog -
	Center	Center	Analog +


12 Identifying Cables

Analog Cables

Agilent 1100/1200 to General Purpose

Connector 01046-60105	Pin 3394/6	Pin Agilent 1100/1200	Signal Name
	1		Not connected
	2	Black	Analog -
	3	Red	Analog +

Remote Cables



One end of these cables provides a Agilent Technologies APG (Analytical Products Group) remote connector to be connected to Agilent 1100/1200 Series modules. The other end depends on the instrument to be connected to.


Agilent 1100/1200 to 3390 Integrators

Connector 01046-60203	Pin 3390	Pin Agilent 1100/1200	Signal Name	Active (TTL)
<p>A diagram of the Agilent 1100/1200 to 3390 Integrator connector. It is a circular connector with nine pins arranged in a circle, numbered 1 through 9. Pin 1 is at the top, pin 2 is at the top-left, pin 3 is at the left, pin 4 is at the bottom-left, pin 5 is at the bottom, pin 6 is at the bottom-right, pin 7 is at the right, pin 8 is at the top-right, and pin 9 is at the top.</p>	2	1 - White	Digital ground	
	NC	2 - Brown	Prepare run	Low
	7	3 - Gray	Start	Low
	NC	4 - Blue	Shut down	Low
	NC	5 - Pink	Not connected	
	NC	6 - Yellow	Power on	High
	NC	7 - Red	Ready	High
	NC	8 - Green	Stop	Low
	NC	9 - Black	Start request	Low


12 Identifying Cables

Remote Cables

Agilent 1100/1200 to 3392/3 Integrators

Connector 01046-60206	Pin 3392/3	Pin Agilent 1100/1200	Signal Name	Active (TTL)
	3	1 - White	Digital ground	
	NC	2 - Brown	Prepare run	Low
	11	3 - Gray	Start	Low
	NC	4 - Blue	Shut down	Low
	NC	5 - Pink	Not connected	
	NC	6 - Yellow	Power on	High
	9	7 - Red	Ready	High
	1	8 - Green	Stop	Low
	NC	9 - Black	Start request	Low


Agilent 1100/1200 to 3394 Integrators

Connector 01046-60210	Pin 3394	Pin Agilent 1100/1200	Signal Name	Active (TTL)
	9	1 - White	Digital ground	
	NC	2 - Brown	Prepare run	Low
	3	3 - Gray	Start	Low
	NC	4 - Blue	Shut down	Low
	NC	5 - Pink	Not connected	
	NC	6 - Yellow	Power on	High
	5,14	7 - Red	Ready	High
	6	8 - Green	Stop	Low
	1	9 - Black	Start request	Low
	13, 15		Not connected	

NOTE

START and STOP are connected via diodes to pin 3 of the 3394 connector.

Agilent 1100/1200 to 3396A Integrators

Connector 03394-60600	Pin 3394	Pin Agilent 1100/1200	Signal Name	Active (TTL)
	9	1 - White	Digital ground	
	NC	2 - Brown	Prepare run	Low
	3	3 - Gray	Start	Low
	NC	4 - Blue	Shut down	Low
	NC	5 - Pink	Not connected	
	NC	6 - Yellow	Power on	High
	5,14	7 - Red	Ready	High
	1	8 - Green	Stop	Low
	NC	9 - Black	Start request	Low
	13, 15		Not connected	


Agilent 1100/1200 to 3396 Series II / 3395A Integrators

Use the cable **part number: 03394-60600** and cut pin #5 on the integrator side. Otherwise the integrator prints START; not ready.


12 Identifying Cables

Remote Cables


Agilent 1100/1200 to 3396 Series III / 3395B Integrators

Connector 03396-61010	Pin 33XX	Pin Agilent 1100/1200	Signal Name	Active (TTL)
	9	1 - White	Digital ground	
	NC	2 - Brown	Prepare run	Low
	3	3 - Gray	Start	Low
	NC	4 - Blue	Shut down	Low
	NC	5 - Pink	Not connected	
	NC	6 - Yellow	Power on	High
	14	7 - Red	Ready	High
	4	8 - Green	Stop	Low
	NC	9 - Black	Start request	Low
	13, 15		Not connected	


Agilent 1100/1200 to HP 1050, HP 1046A or Agilent 35900 A/D Converters

Connector 5061-3378	Pin HP 1050/....	Pin Agilent 1100/1200	Signal Name	Active (TTL)
	1 - White	1 - White	Digital ground	
	2 - Brown	2 - Brown	Prepare run	Low
	3 - Gray	3 - Gray	Start	Low
	4 - Blue	4 - Blue	Shut down	Low
	5 - Pink	5 - Pink	Not connected	
	6 - Yellow	6 - Yellow	Power on	High
	7 - Red	7 - Red	Ready	High
	8 - Green	8 - Green	Stop	Low
	9 - Black	9 - Black	Start request	Low

Agilent 1100/1200 to HP 1090 LC or Signal Distribution Module

Connector 01046-60202	Pin HP 1090	Pin Agilent 1100/1200	Signal Name	Active (TTL)
	1	1 - White	Digital ground	
	NC	2 - Brown	Prepare run	Low
	4	3 - Gray	Start	Low
	7	4 - Blue	Shut down	Low
	8	5 - Pink	Not connected	
	NC	6 - Yellow	Power on	High
	3	7 - Red	Ready	High
	6	8 - Green	Stop	Low
	NC	9 - Black	Start request	Low

Agilent 1100/1200 to General Purpose

Connector 01046-60201	Pin Universal	Pin Agilent 1100/1200	Signal Name	Active (TTL)
		1 - White	Digital ground	
		2 - Brown	Prepare run	Low
		3 - Gray	Start	Low
		4 - Blue	Shut down	Low
		5 - Pink	Not connected	
		6 - Yellow	Power on	High
		7 - Red	Ready	High
		8 - Green	Stop	Low
		9 - Black	Start request	Low

BCD Cables




One end of these cables provides a 15-pin BCD connector to be connected to the Agilent 1200 Series modules. The other end depends on the instrument to be connected to


Agilent 1200 to General Purpose

Connector G1351-81600	Wire Color	Pin Agilent 1200	Signal Name	BCD Digit
	Green	1	BCD 5	20
	Violet	2	BCD 7	80
	Blue	3	BCD 6	40
	Yellow	4	BCD 4	10
	Black	5	BCD 0	1
	Orange	6	BCD 3	8
	Red	7	BCD 2	4
	Brown	8	BCD 1	2
	Gray	9	Digital ground	Gray
	Gray/pink	10	BCD 11	800
	Red/blue	11	BCD 10	400
	White/green	12	BCD 9	200
	Brown/green	13	BCD 8	100
	not connected	14		
	not connected	15	+ 5 V	Low

Agilent 1200 to 3396 Integrators


Connector 03396-60560	Pin 3392/3	Pin Agilent 1200	Signal Name	BCD Digit
	1	1	BCD 5	20
	2	2	BCD 7	80
	3	3	BCD 6	40
	4	4	BCD 4	10
	5	5	BCD0	1
	6	6	BCD 3	8
	7	7	BCD 2	4
	8	8	BCD 1	2
	9	9	Digital ground	
	NC	15	+ 5 V	Low

Auxiliary Cable




One end of this cable provides a modular plug to be connected to the Agilent 1100 Series vacuum degasser. The other end is for general purpose.

Agilent 1100 Series Degasser to general purposes

Connector G1322-81600	Color	Pin Agilent 1100	Signal Name
	White	1	Ground
	Brown	2	Pressure signal
	Green	3	
	Yellow	4	
	Grey	5	DC + 5 V IN
	Pink	6	Vent

CAN/LAN Cables



Both ends of this cable provide a modular plug to be connected to Agilent 1200 Series module's CAN or LAN connectors.


CAN Cables

Agilent 1200 module to module, 0.5 m	5181-1516
Agilent 1200 module to module, 1 m	5181-1519
Agilent 1200 module to control module	G1323-81600

LAN Cables


Description	Part number
Cross-over network cable (shielded, 3 m long), (for point to point connection)	5023-0203
Twisted pair network cable (shielded, 7 m long) (for hub connections)	5023-0202

External Contact Cable



One end of this cable provides a 15-pin plug to be connected to Agilent 1200 Series module's interface board. The other end is for general purpose.

Agilent 1200 Series Interface Board to general purposes

Connector G1103-61611	Color	Pin Agilent 1200	Signal Name
	White	1	EXT 1
	Brown	2	EXT 1
	Green	3	EXT 2
	Yellow	4	EXT 2
	Grey	5	EXT 3
	Pink	6	EXT 3
	Blue	7	EXT 4
	Red	8	EXT 4
	Black	9	Not connected
	Violet	10	Not connected
	Grey/pink	11	Not connected
	Red/blue	12	Not connected
	White/green	13	Not connected
	Brown/green	14	Not connected
	White/yellow	15	Not connected

RS-232 Cables

Description	Part number
RS-232 cable, instrument to PC, 9-to-9 pin (female) This cable has special pin-out, and is not compatible with connecting printers and plotters.	24542U G1530-60600
RS-232 cable kit, 9-to-9 pin (female) and one adapter 9-pin (male) 25-pin female. Suited for instrument to PC.	34398A
Cable Printer Serial & Parallel, is a SUB-D 9 pin female vs. Centronics connector on the other end (NOT FOR FW UPDATE).	5181-1529
This kit contains a 9-pin female to 9-pin female Null Modem (printer) cable and one adapter. Use the cable and adapter to connect Agilent Technologies instruments with 9-pin male RS-232 connectors to most PCs or printers.	34398A

12 Identifying Cables

RS-232 Cables



13 Hardware Information

The Electronics	232
Firmware Description	233
Firmware Updates	234
Agilent 1200 Series Interfaces	235
GPIB Interface	236
CAN Interface	236
Remote Interface	236
RS-232C	238
Setting the 8-bit Configuration Switch	239
GPIB Default Addresses	240
Communication Settings for RS-232C Communication	240
Forced Cold-Start Settings	242
Stay Resident Settings	243
The Main Power Supply Assembly	244

This chapter describes the detector in more detail on hardware and electronics.



The Electronics

The electronics are comprised of four main components:

- column compartment main board (CCM).
- column identification board (CID), see [“Column-Identification System”](#) on page 13
- power supply, see [“The Main Power Supply Assembly”](#) on page 244.

Firmware Description

The firmware of the instrument consists of two independent sections:

- a non-instrument specific section, called ‘resident system’,
- an instrument specific section, called ‘main system’.

Resident System

This resident section of the firmware is identical for all Agilent 1200 series modules. Its properties are:

- the complete communication capabilities (GPIB, CAN, LAN and RS-232C),
- memory management,
- ability to update the firmware of the ‘main system’.

Main System

Its properties are:

- the complete communication capabilities (GPIB, CAN, LAN and RS-232C),
- memory management,
- ability to update the firmware of the ‘resident system’.

In addition the main system comprises the instrument functions that are divided into common functions like

- run synchronization via APG remote
- error handling,
- diagnostic functions and so on,

or module specific functions like

- internal events such as heater control, column identification,
- and so on.

Firmware Updates

Firmware updates can be done using your user interface:

- hand-held control module with files from a PC-card or
- Agilent ChemStation with files from floppy disk

The file naming conventions are:

1316A_A601_12.dlb

xxxx is the product number, e.g. 1316 for the G1316A TCC, and vvv is the revision number, for example A601 is revision A.06.01, and zz is the build number

For instructions refer to your user interface.

NOTE

Update of main system can be done in the resident system only. Update of the resident system can be done in the main system only.




Figure 45 Firmware Update Mechanism

Agilent 1200 Series Interfaces

The Agilent 1200 Series modules provide the following interfaces:

Interface Type	Pumps	Autosampler	DA Detector MW Detector FL Detector	DA Detector MW Detector (G1315C/G1365C)	VW Detector RI Detector	Thermostatted Column Compartment	Vacuum Degasser
CAN	Yes	Yes	Yes	Yes	Yes	Yes	No
LAN (on-board)	No	No	No	Yes	No	No	No
GPIB	Yes	Yes	Yes	No	Yes	No	No
RS-232C	Yes	Yes	Yes	Yes	Yes	Yes	No
Remote	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Analog	Yes	No	2 ×	2 ×	1 ×	No	Yes ¹
Interface board (LAN/BCD/Ext)	Yes	Yes	Yes	No	Yes	No	No

¹ The vacuum degasser will have a special connector for specific use. For details see description of main board.

- CAN connectors as interface to other Agilent 1200 Series modules,
- GPIB connector as interface to the Agilent ChemStation,
- RS-232C as interface to a computer,
- REMOTE connector as interface to other Agilent products,
- analog output connector(s) for signal output, and
- interface slot for specific interfacing (external contacts, BCD, LAN and so on).

For identification and location of the connectors see [Figure 12](#) on page 41.

NOTE

Never use cables other than the ones supplied by Agilent Technologies to ensure proper functionality and compliance with safety or EMC regulations, see [“Cable Overview”](#) on page 214.

GPIB Interface

The GPIB connector is used to connect the module with a computer. The address and control switches next to the GPIB connector determine the GPIB address of your module. The switches are preset to a default address and recognized by the operating software from Agilent Technologies.

Table 44 Default Addresses

Autosampler	28	Autosampler	28
Pump	22	RID	29
FLD	23		
VWD	24	Autosampler (HP 1050)	11
Agilent 8453A	25	Pump (HP 1050)	12
DAD/MWD	26	VWD (HP 1050)	10
Column Compartment	27	DAD (HP 1050)	17

CAN Interface

The CAN is an intermodule communication interface. It is a 2 wire serial bus system supporting high speed data communication and real-time requirement.

Remote Interface

The APG Remote connector may be used in combination with other analytical instruments from Agilent Technologies if you want to use features as common shut down, prepare, and so on.

Remote control allows easy connection between single instruments or systems to ensure coordinated analysis with simple coupling requirements.

The subminiature D connector is used. The module provides one remote connector which is inputs/outputs (wired-or technique).

To provide maximum safety within a distributed analysis system, one line is dedicated to SHUT DOWN the system's critical parts in case any module detects a serious problem. To detect whether all participating modules are switched on or properly powered, one line is defined to summarize the POWER ON state of all connected modules. Control of analysis is maintained by signal readiness READY for next analysis, followed by START of run and optional STOP of run triggered on the respective lines. In addition PREPARE and START REQUEST may be issued. The signal level are defined as:

- standard TTL levels (0 V is logic true, + 5 V is false)
- fan-out is 10,
- input load is 2.2 kOhm against + 5 V, and
- output are open collector type, inputs/outputs (wired-or technique).

Table 45 Remote Signal Distribution

Pin	Signal	Description
1	DGND	Digital ground
2	PREPARE	(L) Request to prepare for analysis (for example, calibration, detector lamp on). Receiver is any module performing preanalysis activities.
3	START	(L) Request to start run / timetable. Receiver is any module performing run-time controlled activities.
4	SHUT DOWN	(L) System has serious problem (for example, leak: stops pump). Receiver is any module capable to reduce safety risk.
5		Not used
6	POWER ON	(H) All modules connected to system are switched on. Receiver is any module relying on operation of others.
7	READY	(H) System is ready for next analysis. Receiver is any sequence controller.
8	STOP	(L) Request to reach system ready state as soon as possible (for example, stop run, abort or finish and stop injection). Receiver is any module performing run-time controlled activities.
9	START REQUEST	(L) Request to start injection cycle (for example, by start key on any module). Receiver is the autosampler.


RS-232C

The RS-232C connector is used to control the column module from a computer through RS-232C connection, using the appropriate software. This connector can be configured with the configuration switch module next to the GPIB connector.

The RS-232C is designed as DCE (data communication equipment) with a 9-pin male SUB-D type connector. The pins are defined as:

Table 46 RS-232C Connection Table

Pin	Direction	Function
1	In	DCD
2	In	RxD
3	Out	TxD
4	Out	DTR
5		Ground
6	In	DSR
7	Out	RTS
8	In	CTS
9	In	RI



Setting the 8-bit Configuration Switch

The 8-bit configuration switch is located next to the GPIB connector. Switch settings provide configuration parameters for GPIB address, serial communication protocol and instrument specific initialization procedures.




Table 47 8-bit Configuration Switch

Mode Select	1	2	3	4	5	6	7	8
GPIB	0	0	GPIB Address					
RS-232C	0	1	Baudrate			Data Bits	Parity	
Reserved	1	0	Reserved					
TEST/BOOT	1	1	RSVD	SYS		RSVD	RSVD	FC

Switches 1 and 2 define which set of parameters (for example, for GPIB, RS-232C, and so on) will be changed. Once the change has been completed, the instrument must be powered up again in order to store the values in the non-volatile memory.

13 Hardware Information

Setting the 8-bit Configuration Switch

Here the parameters are kept, independently if you turn the column compartment off and on again. They will be kept until the same set of parameters is subsequently changed and power is reset. All other previously stored configuration settings are still being kept in non-volatile memory.

In this manner you can store more than one set of parameters, for example, for GPIB and RS-232C, using the same 8-bit configuration switch twice.

GPIB Default Addresses

If you just want to change the GPIB address and need a detailed procedure, refer to the *Installing Your Agilent ChemStation System* handbook. Default GPIB address is set to the following addresses:

Table 48 Default Addresses for Agilent 1200 Series Modules

Module	Address	Binary Address
Pump	22	0 0 0 1 0 1 1 0
FLD	23	0 0 0 1 0 1 1 1
VWD	24	0 0 0 1 1 0 0 0
Agilent 8453A	25	0 0 0 1 1 1 0 1
DAD/MWD	26	0 0 0 1 1 0 1 0
Column compartment	27	0 0 0 1 1 0 1 1
Autosampler	28	0 0 0 1 1 1 0 0
RID	29	0 0 0 1 1 1 0 1

where 0 means that the switch is down and 1 means that the switch is up.

Communication Settings for RS-232C Communication

The communication protocol used in the column compartment supports only hardware handshake (CTS/RTR).

Switches 1 in down and 2 in up position define that the RS-232C parameters will be changed. Once the change has been completed, the column instrument must be powered up again in order to store the values in the non-volatile memory.

Table 49 Communication Settings for RS-232C Communication

Mode Select	1	2	3	4	5	6	7	8
RS-232C	0	1	Baudrate			Data Bits	Parity	

Use the following tables for selecting the setting which you want to use for RS-232C communication. The number 0 means that the switch is down and 1 means that the switch is up.

Table 50 Baudrate Settings

Switches			Baud Rate	Switches			Baud Rate
3	4	5		3	4	5	
0	0	0	9600	1	0	0	9600
0	0	1	1200	1	0	1	14400
0	1	0	2400	1	1	0	19200
0	1	1	4800	1	1	1	38400

Table 51 Data Bit Settings

Switch 6	Data Word Size
0	7 Bit Communication
1	8 Bit Communication

Table 52 Parity Settings

Switches		Parity
7	8	
0	0	No Parity

13 Hardware Information

Setting the 8-bit Configuration Switch

Table 52 Parity Settings

1	0	Odd Parity
1	1	Even Parity

One start bit and one stop bit are always used (not selectable).

Per default, the module will turn into 19200 baud, 8 data bit with no parity.

Forced Cold-Start Settings

Switches 1 and 2 do not force storage of this set of parameters in non-volatile memory. Returning the switches 1 and 2 to other positions (other than being both up) will allow for normal operation.

CAUTION

Forced cold start erases all methods and data stored in the non-volatile memory. Except the diagnose and repair log books all methods and data will be erased.

→ Make sure that all important methods and data are stored before you enforce a cold start

If you use the following switch settings and power the instrument up again, a forced cold start has been completed.

Table 53 Forced Cold Start Settings

Mode Select	1	2	3	4	5	6	7	8
TEST/BOOT	1	1	0	0	0	0	0	1

To return to normal operation, set switches back to your GPIB or RS 232C configuration settings.

Stay Resident Settings

Firmware update procedures may require this mode in case of firmware loading errors.

Switches 1 and 2 do not force storage of this set of parameters in non-volatile memory. Returning the switches 1 and 2 to other positions (other than being both up) will allow for normal operation.

If you use the following switch settings and power the instrument up again, the instrument firmware stays in the resident part, that is, it is not operable as a column compartment. It only uses basic functions of the operating system, for example, for communication.

Table 54 Stay Resident Settings


Mode Select	1	2	3	4	5	6	7	8
TEST/BOOT	1	1	0	0	1	0	0	0

To return to normal operation, set switches back to your GPIB or RS 232C configuration settings.

The Main Power Supply Assembly

The main power supply comprises a closed assembly and must not be disassembled further for safety reasons. In case of a defect, the entire power supply needs to be replaced.

The power supply provides all DC voltages used in the module. The line voltage can vary in a range from 100 – 240 volts AC \pm 10 % and needs no manual setting.



NOTE

To disconnect the instrument from line, unplug the power cord. The power supply still uses some power, even if the power switch on the front panel is turned off.

No accessible hardware fuse is needed because the main power supply is safe against any short circuits or overload conditions on the output lines. When overload conditions occur, the power supply turns off all output voltages. Turning the line power off and on again resets the power supply to normal operation if the cause of the overload condition has been removed.

An over-temperature sensor in the main power supply is used to turn off output voltages if the temperature exceeds the acceptable limit (for example, if the cooling fan of the instrument fails). To reset the main power supply to normal operating conditions, turn the instrument off, wait until it is approximately at ambient temperature and turn the instrument on again.

The following table gives the specifications of the main power supply.

Table 55 Power Supply Specifications (Standard)

Maximum power	160 VA / 130 W	Continuous output
Line Input	100 – 240 volts AC \pm 10 %, line frequency of 50/60 Hz	Wide ranging
Pin 1	Power Fail	error message
Pin 2	AGND	
Pin 3	-15 VDC	
Pin 4	+15 VDC	
Pin 5	PGND	
Pin 6	PGND	
Pin 7	+24 VDC	
Pin 8	+24 VDC	
Pin 9	+36 VDC	not used
Pin 10	+36 VDC	not used
Pin 11	DGND	
Pin 12	+ 5 VDC	

13 Hardware Information

The Main Power Supply Assembly



14 Appendix

Safety Symbols	248
The Waste Electrical and Electronic Equipment Directive	251
Lithium Batteries Information	252
Radio Interference	253
Sound Emission	254
Solvent Information	255
Agilent Technologies on Internet	257






This chapter provides addition information on safety, legal and web.



Safety Symbols

Safety Symbols

Table 56 Safety Symbols

Symbol	Description
	The apparatus is marked with this symbol when the user should refer to the instruction manual in order to protect risk of harm to the operator and to protect the apparatus against damage.
	Indicates dangerous voltages.
	Indicates a protected ground terminal.
	Indicates eye damage may result from directly viewing the light produced by the deuterium lamp used in this product.
	The apparatus is marked with this symbol when hot surfaces are available and the user should not touch it when heated up.

WARNING

A WARNING

alerts you to situations that could cause physical injury or death.

- Do not proceed beyond a warning until you have fully understood and met the indicated conditions.

CAUTION

A CAUTION

alerts you to situations that could cause loss of data, or damage of equipment.

- Do not proceed beyond a caution until you have fully understood and met the indicated conditions.

General Safety Information

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. Agilent Technologies assumes no liability for the customer's failure to comply with these requirements.

WARNING

Ensure the proper usage of the equipment.

The protection provided by the equipment may be impaired.

→ The operator of this instrument is advised to use the equipment in a manner as specified in this manual.

General

This is a Safety Class I instrument (provided with terminal for protective earthing) and has been manufactured and tested according to international safety standards.

Operation

Before applying power, comply with the installation section. Additionally the following must be observed.

Do not remove instrument covers when operating. Before the instrument is switched on, all protective earth terminals, extension cords, auto-transformers, and devices connected to it must be connected to a protective earth via a ground socket. Any interruption of the protective earth grounding will cause a potential shock hazard that could result in serious personal injury. Whenever it is likely that the protection has been impaired, the instrument must be made inoperative and be secured against any intended operation.

Make sure that only fuses with the required rated current and of the specified type (normal blow, time delay, and so on) are used for replacement. The use of repaired fuses and the short-circuiting of fuse holders must be avoided.

14 Appendix

Safety Symbols

Some adjustments described in the manual, are made with power supplied to the instrument, and protective covers removed. Energy available at many points may, if contacted, result in personal injury.

Any adjustment, maintenance, and repair of the opened instrument under voltage should be avoided whenever possible. When inevitable, this has to be carried out by a skilled person who is aware of the hazard involved. Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present. Do not replace components with power cable connected.

Do not operate the instrument in the presence of flammable gases or fumes. Operation of any electrical instrument in such an environment constitutes a definite safety hazard.

Do not install substitute parts or make any unauthorized modification to the instrument.

Capacitors inside the instrument may still be charged, even though the instrument has been disconnected from its source of supply. Dangerous voltages, capable of causing serious personal injury, are present in this instrument. Use extreme caution when handling, testing and adjusting.

When working with solvents please observe appropriate safety procedures (e.g. goggles, safety gloves and protective clothing) as described in the material handling and safety data sheet by the solvent vendor, especially when toxic or hazardous solvents are used.

The Waste Electrical and Electronic Equipment Directive

Abstract

The Waste Electrical and Electronic Equipment (WEEE) Directive (2002/96/EC), adopted by EU Commission on 13 February 2003, is introducing producer responsibility on all electric and electronic appliances starting with 13 August 2005.

NOTE

This product complies with the WEEE Directive (2002/96/EC) marking requirements. The affixed label indicates that you must not discard this electrical/electronic product in domestic household waste.

Product Category:

With reference to the equipment types in the WEEE Directive Annex I, this product is classed as a "Monitoring and Control Instrumentation" product.

NOTE



Do not dispose off in domestic household waste

To return unwanted products, contact your local Agilent office, or see www.agilent.com for more information.

Lithium Batteries Information

WARNING

Lithium batteries may not be disposed-off into the domestic waste. Transportation of discharged Lithium batteries through carriers regulated by IATA/ICAO, ADR, RID, IMDG is not allowed.

Danger of explosion if battery is incorrectly replaced.

- Discharged Lithium batteries shall be disposed off locally according to national waste disposal regulations for batteries.
- Replace only with the same or equivalent type recommended by the equipment manufacturer.



WARNING

Lithiumbatteri - Eksplosionsfare ved fejlagtig håndtering.

Udskiftning må kun ske med batteri af samme fabrikat og type.

- Lever det brugte batteri tilbage til leverandøren.

WARNING

Lithiumbatteri - Eksplosionsfare.

Ved udskiftning benyttes kun batteri som anbefalt av apparatfabrikanten.

- Brukt batteri returneres apparatleverandøren.

NOTE

Bij dit apparaat zijn batterijen geleverd. Wanneer deze leeg zijn, moet u ze niet weggooien maar inleveren als KCA.

Radio Interference

Cables supplied by Agilent Technologies are screened to provide optimized protection against radio interference. All cables are in compliance with safety or EMC regulations.

Test and Measurement

If test and measurement equipment is operated with unscreened cables, or used for measurements on open set-ups, the user has to assure that under operating conditions the radio interference limits are still met within the premises.

Sound Emission

Manufacturer's Declaration

This statement is provided to comply with the requirements of the German Sound Emission Directive of 18 January 1991.

This product has a sound pressure emission (at the operator position) < 70 dB.

- Sound Pressure $L_p < 70$ dB (A)
- At Operator Position
- Normal Operation
- According to ISO 7779:1988/EN 27779/1991 (Type Test)

Solvent Information

Flow Cell


To protect optimal functionality of your flow-cell:

- Avoid the use of alkaline solutions (pH > 9.5) which can attack quartz and thus impair the optical properties of the flow cell.
- If the flow cell is transported while temperatures are below 5 degree C, it must be assured that the cell is filled with alcohol.
- Aqueous solvents in the flow cell can build up algae. Therefore do not leave aqueous solvents sitting in the flow cell. Add a small % of organic solvents (e.g. acetonitrile or methanol ~5%).

Use of Solvents

Observe the following recommendations on the use of solvents.

- Brown glass ware can avoid growth of algae.
- Small particles can permanently block capillaries and valves. Therefore always filter solvents through 0.4 µm filters.
- Avoid the use of the following steel-corrosive solvents:
 - Solutions of alkali halides and their respective acids (for example, lithium iodide, potassium chloride, and so on),
 - High concentrations of inorganic acids like sulfuric acid and nitric acid, especially at higher temperatures (if your chromatography method allows, replace by phosphoric acid or phosphate buffer which are less corrosive against stainless steel),
 - Halogenated solvents or mixtures which form radicals and/or acids, for example:



This reaction, in which stainless steel probably acts as a catalyst, occurs quickly with dried chloroform if the drying process removes the stabilizing alcohol,

14 Appendix

Solvent Information

- Chromatographic grade ethers, which can contain peroxides (for example, THF, dioxane, di-isopropylether) such ethers should be filtered through dry aluminium oxide which adsorbs the peroxides,
- Solvents containing strong complexing agents (e.g. EDTA),
- Mixtures of carbon tetrachloride with 2-propanol or THF.

Agilent Technologies on Internet

For the latest information on products and services visit our worldwide web site on the Internet at:

<http://www.agilent.com>

Select Products/Chemical Analysis

It will provide also the latest firmware of the Agilent 1200 Series modules for download.

Index

A

- Agilent
 - Diagnostic Software 22, 60
 - Lab Advisor Software 22, 60
 - on internet 257
- algae 255, 255
- ambient operating temperature 27
- ambient non-operating temperature 27
- analog
 - cable 214, 216
- auxiliary
 - cable 214, 226

B

- battery
 - safety information 252
- BCD
 - cable 214, 224
- bench space 26

C

- cable
 - analog 214, 216
 - auxiliary 214, 226
 - BCD 214, 224
 - CAN 227
 - external contact 228
 - external contacts 215
 - GPIO 215
 - LAN 215, 227
 - remote 214, 219
 - RS-232 215, 229
- cables
 - overview 214
- calibration
 - temperature 56, 80
- CAN interface 236
- CAN
 - cable 227
- changing
 - serial number and type 129
- ChemStation
 - changing serial number and type 130
 - recover type 136
- column switching valve (optional)
 - description 15
 - precolumn backflushing 17
- column switching valve (optional)
 - two column selection 16
- column switching valve
 - installing 119
- column clip 50
- column identification
 - tag 49
- column temperature 72
- column
 - changing column and tags 91
- compensation sensor open 67
- compensation sensor short 67
- configuration switch
 - default settings 239
 - description and factory settings 239
- Control Module
 - changing serial number and type 132
 - recover type 137
- cool-down time 28
- cooling concept 11

- cooling device
 - post column 30
- cover violation 69

D

- dead volume 28
- defective heater circuit 73
- defective temperature sensor 70
- delivery checklist 34
- Diagnostic
 - software 22, 60
- dimensions 27

E

- electrical connections
 - descriptions of 18
- electronic waste 251
- electronics 232
- electrostatic discharge (ESD) 88, 109
- environment 26
- error messages
 - column temperature 72
 - compensation sensor open 67
 - compensation sensor short 67
 - cover violation 69
 - defective heater circuit 73
 - defective temperature sensor 70
 - heater profile 70
 - heatsink temperature 72
 - introduction 62
 - leak sensor open 66
 - leak sensor short 66
 - leak 65
 - left fan failed 67

Index

- left temperature timeout 69
- open cover 68
- remote timeout 64
- right fan failed 68
- right temperature timeout 69
- shut-down 64
- timeout 63
- valve failed 71
- external measuring device
 - information 82
- external contact
 - cable 215, 228
- F**
- features
 - GLP 28, 29
 - instrument layout 21
 - safety and maintenance 28
- firmware
 - main system 233
 - resident system 233
 - updates 234
- flow cell 255
 - solvent information 255
- forced cold-start setting 242
- frequency range 27
- function test
 - failed 78
 - result 76
- fuses
 - none in the instrument 244
- G**
- GLP features 28
- GPIB
 - cable 215
 - default addresses 240
 - interface 236
- H**
- heater profile 70
- heaterechanger
 - pre-column 30
- heating concept 11
- heatsink temperature 72
- humidity 27
- I**
- installation
 - bench space 26
 - capillaries and waste tubings 46
 - column switching valve 119
 - column 45, 45
 - flow connections 44
 - module 38
 - power cords 25
 - temperature sensor 83
 - unpacking 34
- Instant Pilot
 - changing serial number and type 132
 - recover type 136
- instrument layout 21
- interfaces
 - APG remote 236
 - CAN 236
 - GPIB 236
 - RS-232C 238
- internet 257
- introduction
 - concept of heating and cooling 11
 - system overview 11
- L**
- Lab Advisor
 - software 22, 60
- LAN
 - cable 215, 227
- leak sensor short 66
- leak sensor open 66
- leak 65
- leaks, correcting 99
- left fan failed 67
- left temperature timeout 69
- line frequency 27
- line voltage 27
- lithium batteries 252
- LMD
 - changing serial number and type 129
 - recover type and firmware 136
 - recovery type only 135
- M**
- main assemblies 200
- N**
- non-operating altitude 27
- non-operating temperature 27
- O**
- open cover 68
- operating Altitude 27
- operating temperature 27
- optimization 51
- optimizing the performance 52
- P**
- parts identification
 - leak panels 196
- parts identification
 - column switching valve 203
 - foams 207
 - main assemblies 200
 - plastics 188, 205
 - power and status 209

Index

- sheet metal kit 203
- performance
 - Optimization 51
 - optimizing 52
 - specifications and features 28
- physical specifications 27
- physical specifications 27
- post-column
 - cooling device 30
- power settings (autoranging) 244
- power consideration 24
- power consumption 27
- power cords 25
- power supply
 - description 244
- pre-column
 - heatexchanger 30

R

- radio interference 253
- recover
 - wrong type 134
- remote (APG) interface 236
- remote timeout 64
- remote
 - cable 214, 219
- Removing the Top Cover and Foam 110
- repairs
 - assembling main cover 168
 - changing the column 91
 - cleaning the instrument 90
 - column switching valve parts 93
 - correcting leaks 99
 - exchanging processor board (CCM) 124
 - exchanging the fan 138
 - installing column switching valve 119
 - installing foam and top cover 162
 - installing heat exchangers 145

- internal parts 108
- introduction 86
- overview 89
- removing column switching valve 114
- removing heat exchangers 140
- removing top cover and foam 110
- replacing leak sensor and leak base 156
- replacing status light pipe 161
- types simple/internal 86
- warnings and cautions 86
- right fan failed 68
- right temperature timeout 69
- RS-232
 - cable 215
- RS-232C
 - cable 229
 - communication settings 240
 - interface 238

S

- safety class I 249
- safety information
 - lithium batteries 252
- safety
 - general information 249
 - standards 27
 - symbols 248, 248
- serial number
 - information 20
- serial number/type
 - using Agilent Diagnostic software 129
 - using ChemStation 130
 - using Control Mmodule 132
 - using Instant Pilot 132
- serial number
 - changing 129
- setting the addresses 239

- setting
 - forced cold-start 242
- shut-down 64
- site requirements
 - environment 26
- solvent information 255
- solvents 255
- sound emission 254
- specification
 - physical 27
- specifications 28
- stack configuration 35
- status indicators 56, 57
- system overview 11

T

- tag
 - installation 49
- temperature verification
 - principle 83
- temperature calibration
 - description 80
 - problems 83
 - procedure 82
- temperature verification
 - external measuring device 82
- temperature
 - range 28
- tests
 - available tests vs interface 59
- test
 - thermostat function test failed 78
 - thermostat function test result 76
 - thermostat function test 56
- timeout 63
- troubleshooting
 - available tests vs interface 59
 - error messages 56
 - status indicators 56, 57

Index

- type recover
 - with ChemStation 136
 - with Control Module 137
 - with Instant Pilot 136
- type and firmware recover
 - with LMD 136
- type recover
 - with LMD 135
- type
 - changing 129

U

- unpacking 34
- User Interfaces
 - diagnostic tests 59

V

- valve failed 71
- verification
 - temperature 56
- voltage range 27

W

- warm-up time 28
- waste
 - electrical and electronic equipment 251
- WEEE directive 251
- weight 27

In This Book

This manual contains technical reference information about the Agilent 1200 Series thermostatted column compartment.

The manual describes the following:

- introduction and specifications,
- installation,
- using and optimizing,
- troubleshooting and diagnose,
- maintenance and repair,
- parts identification,
- hardware information,
- safety and related information.

© Agilent Technologies 1995, 1996-2008

Printed in Germany
09/2008



G1316-90111



Agilent Technologies