

Turbochrom Tip – How to Reset the 600 Series LINK box

1. Turn the power to the LINK box OFF.
2. Set DIP SWITCH 8 to ON.
3. Turn the power to the LINK box ON.
4. You should see the lights cycling on the LINK box like a Christmas tree unless it is an integral LINK.
5. Set DIP SWITCH 8 to OFF.
6. Now you should see all the error lights on the LINK box.
7. Turn the power to the LINK box OFF.
8. Count to 15.
9. Turn the power to the LINK box back ON.